

Digital Weighing Indicator

SI 200

Instruction Manual



Ver. 1.18

CONTENTS

1. Before Installation	-----	3 Page
2. Introduction	-----	4 Page
3. Installation	-----	6 Page
4. Set-up	-----	10 Page
4-1. Calibration	-----	10 Page
4-2. Test Weight Calibration	-----	10 Page
4-3. Simulating Calibration	-----	13 Page
4-4. TEST mode	-----	16 Page
4-5. F-FUNCTION Setting	-----	18 Page
4-6. F-FUNCTION List	-----	20 Page
4-7. F-FUNCTION explanation	-----	21 Page
5. Interface	-----	24 Page
5-1. RS-232C	-----	24 Page
5-2. RS-485	-----	24 Page
5-3 Data format	-----	25 Page
5-4.Command mode	-----	26 Page
5-5.Command mode ex	-----	30 Page
5-6.Print Interface	-----	32 Page
6. Error & Treatment	-----	35 Page
Warrantee Certificate	-----	37Page

1. BEFORE INSTALLATION

1-1. Caution / Warning Marks



Warning

This mark warns the possibility to arrive death or serious injury in case of wrongly used.



Cautions

This mark cautions the possibility to arrive serious human body injury or product lose in case of wrongly used.

1-2. Copy Rights

- ① All Right and Authority for this Manual is belonged to SEWHA CNM CO., LTD.
- ② Any kinds of copy or distribution without permission of SEWHA CNM CO., LTD. will be prohibited.
- ③ This manual may be changed as the version is upgraded, without previous notice.
You can get the information at our website.

1-3. Inquiries

If you have any kinds of inquiries for this model, please contact your local agent or Head Office.

Head Office : SEWHA CNM CO., LTD.

Website : <http://www.sewhacnm.co.kr>

Email : sales@sewhacnm.co.kr

2. INTRODUCTION


2-1. Features

- As a Wall / Rail Mounting type Indicator, it is convenient to set them at the narrow site because of the small size. Especially at the control panel it is very easy and gives you enough spaces.
- Polycarbonate film panel, strong for dust and water.
- RS-232/485 is standard for more serial interface.(Selectable)
- Data Back-up function for case of that when the power suddenly off.


2-2. Specification

Content			Specification
Performance	External Resolution		1/20,000
	Internal Resolution		1/2,097,152 (±1,048,576)
	Input Sensitivity		Min 0.1μV/V
	Max. Signal Input Voltage		3.00mV/V
	Load cell Excitation		DC +5V
	A/D Conversion Method		Sigma-Delta
	Decimal Point		0, 0.0, 0.00, 0.000
	Drift	Offset	10PPM/°C
		Span	10PPM/°C
	Linearity		0.001% of Full Scale
Analogue Sampling(sec)		60times / sec	
Environment	Operating Temperature Range		-10°C ~ +40°C [14°F ~ 104°F]
	Operation Humidity Range		40% ~ 85% RH, Non-condensing
Function	Test Weight Calibration Mode / Simulation Calibration Mode (Without Test Weight)		
	Display	6 digit, 7.6mm(0.3inch)Yellow green FND	
	4ea standard Key		
Comm.	Serial Interface (RS-232C/RS-485 selectable)		Data Transference Command Mode Serial Printer Mode
Power	Input Power DC 9 ~ 12VPower Consumption MAX 8W		
Size	49mm(W) × 96mm(H) × 41mm(D) -body , Weight : 140g		

2-3. Application




Truck Scale




Crane Scale



Tester






Animal Scale



Tank Scale


2-4. SEWHACNM 's other indicators

SI 4000series 	SI 4000	SI 4010/R	SI 4100	SI 4200
	Simple type	Simple /Controller	Universal Controller	Counter
SI 4630Simple/ Wall mounting 	SI 4300	SI 4400	SI 4410	SI 4500
	Checker	Packer	Filler	Accumulation Controller
	SI 480	SI 580	SI 480/580 DIN Size	
	Simple Din size	Din size Controller		

3. INSTALLATION


3-1. Dimension

(unit : mm)



3-2. Front Panel

3-2-1. Image



3-2-1. State Lamp

STEADY	When the weight is "STEADY", Lamp is ON.
ZERO	When the current weight is "ZERO", Lamp is ON.
TARE	"TARE" function is set, Lamp is ON.
RTxD	RxD-Red, TxD-Green [F-39 setting]






3-2-2. Connectors

LOAD CELL					Serial Interface					POWER	
1	2	3	4	5	6	7		8		9	10
SHLD	SIG -	SIG +	EXC -	EXC +	GND	RS485 RTx -	RS232C TxD	RS485 RTx +	RS232C RxD	GND	DC +12V







Please check the Comm. and other specification in the label, attached on the cover plate first, and make connection according to that information.

3-2-3. Key Operation

	<ul style="list-style-type: none"> - Make Weight value as Zero. - Refer to F-07,F-08
	<ul style="list-style-type: none"> - Set the TARE Function .(F09 setting) - Refer to F-14
	<ul style="list-style-type: none"> - Press this key 4times, within 2secs, enter “SET-UP” mode. -Refer to F14, F15
	<ul style="list-style-type: none"> - Under “TARE” setting, you can select weight display mode. - First input, Gross Weight will be displayed, second input, Net weight will be displayed. ※ This key will be activated only under “TARE” set. In this case  set G(gross weight) will display in front of the value. -TARE RESET key (refer to F14)

● HOT Key (with F key)

 + 	<ul style="list-style-type: none"> - TARE RESET (Refer to F 15) - PRINT (Refer to F15)
 + 	<p>If the Printer is installed, You can print out the “Grand-total data”. (GRAND-total data can be checked though Print output).</p>



Max. accumulated weighing count : 999,999 times

Over 999,999times → return to “0” time

Max. accumulated weight display : 999,999,999

Over 999,999,999 → return to “0”


3-3. Load Cell Installation



Load Cell Wire Connection (In case of SEWHACNM's Load cell)

It depends on the manufacturer of load cell, please check the specification.

3-3-1. Load Cell Wiring



SI 200 wiring with SEWHACNM Load cell



When you use the load cell as tension type, you have to connect SIG+, SIG-crossed.

If you connect other wires to Load cell terminal wrongly, it may cause damage in the analogue board.

Before connecting the load cell cable you have to power off and be sure to connect the cable to the terminal correctly.

















Never do not weld near the load cells , Indicators or other devices.

3-3-2. Installation Cautions

1. You can connect Max. 8pcs of same capacity Load cells at once. (350 Ω)
2. You have to make horizontal balance on the ground.
3. If you install more than 2pcs of load cells, use Summing box and adjust output signal difference as minimum. It can make wrong weighing process caused by each load cell's variation.
4. If there is some temperature difference around Load cell, it can cause wrong weight measurement.
5. Don't do Welding job or Arc discharge around installation place. But, there is no choice, please disconnect power cable and Load cell cable.
6. If you measure static electricity material, please make earth between down part and up part of Load cell.

4. SET UP

● Entering each modes


Calibration	Test weight Calibration	CAL Switch → 
	Simulation Calibration	CAL Switch →  → 
F-FUNCTION mode		 key 4times → 
TEST mode	Key TEST	 key 4times →  → 
	Analog board TEST	 key 4times →  → 
	Communication TEST	 key 4times →  → 

4-1. Calibration [Adjusting “ZERO” Balance]

Adjust weight balance between “Real weight” on the load cell(Weight Part) and “Displayed weight of Indicator”. When you replace LOAD CELL or Indicator, you have to Calibrate process once again.


4-2. Test weight Calibration Mode

4-2-1. Step


Step	How to
1 Enter Calibration mode	Push CAL switch(top of the indicator)
2 Enter test weight Calibration mode	Input  key
3 Input the Rated Capacity (Rated.Capa or Max Capa)	Ex) 20kg
4 Input division (Minimum unit)	Ex) 0.001
5 ZERO Calibration	Without anything on the Load cell
6 SPAN Calibration	With the test weight over Max capa's 10% Ex) When R.C is 20kg, test weight must be over 2kg

4-2-2. Test weight calibration Mode


1. Calibration Mode






Push CAL switch in normal mode.

When it displays press  key to enter test weight calibration mode.


2. Rated Capacity[Max Capa]






It is step to set rated capacity or max capa.

Input the max capa(or rated capacity) with  key & . Then press  key to save it & move to next step. Ex) Max capa : 20kg

3. Division[Min unit]




It is step to set division[min unit].

Input the decimal point, digit, division(min unit) with  key & . Then press  key to save .. Ex) Division(min unit) 0.001kg.

4. ZERO Calibration




It is step to set ZERO(Dead) calibration, without anything on the load cell. and press  key.

ZERO calibration is processing for 10 seconds.

5. SPAN Calibration



It is step to set test weight information.

Input the weight of test weight (over 10% of Rated capa or Max capa), and press  key to save.

Load the test weight & input  key.




SPAN Calibration is processing for about 10 seconds.

After calculation, when span value shows input **F** key to save.

All of the calibration step is over.

- Pressing **NET GROSS** key means calcel, pressing **F** key means saving or going next.

4-2-3. Test weight calibration cause & treatment



It shows in case of $\frac{\text{Rated capa [Max Capa]}}{\text{Division[Min unit]}} > 20,000$.

Ex) When Rated capa[Max capa] is 20,000kg , division[Min unit] cannot be under 1kg

It shows when the Test weight > Rated capa[Max capa]

→Then please re-input right value again.

The more heavy test weight makes the more accurate measurement.

It shows when the Test weight < 10% of Rated capa[Max capa]

→ Then Please re-input right value agian.

Amp. Gain is too big

Sig+/- wiring is connected wrongly.

The test weight is not loaded.

Amp. Gain is too small

Sig+/- wiring is connected wrongly.

The test weight is not loaded.

there is vibration on the load cell or load cell wire, the indicator cannot calculate calibration anymore.



4-3. Simulation Calibration Mode(Calibrate without test weight)

With this “Simulation Calibration Mode” you can make simple calibration without any “TEST weight”

This calibration mode uses “Load cells’ max capacity” and “Max. Output Rate(mV)”, so the weight adjustment degree might be less than “Test weight Calibration”.

The guaranteed resolution of this “Simulation Calibration” is $\frac{1}{3,000}$.

4-3-1. Simulation Calibration Step

Step	How to
1 Enter Calibration Mode	Push CAL Switch
2 Enter Simulation Calibration mode	Input  key &  key.
3 Input the Rated Capacity [Max Capa]	Ex) 150kg
4 Input division [Min unit)	Ex) 0.05
5 ZERO Calibration	Without anything on the Load cell
6 SPAN Calibration	Input the Rated Output value (mV/V) 예) 1.987mV/V → input 1.98700

4-3-2. Simulation Calibration Mode


1. Calibration Mode



Push CAL switch in normal mode.

Press  key &  key to enter simulation calibration mode.


2. Rated Capacity(Max Capa)




It is step to set rated capacity(written on the load cell label)

Input the rated capacity with  key &  . Then press  key to save it & move to next step. Ex) Max capa : 150kg

3. Division[Min unit)



It is step to set division[min unit].

Input the decimal point, digit, division(min unit) with  key &



key. Then press **F** key to save .. Ex) Division(min unit) 0.05kg.

4. ZERO Calibration



It is step to set ZERO(Dead) calibration, without anything on the load cell and press **F** key.

ZERO calibration is processing for 10 seconds.

5. SPAN Calibration



It is step to input load cell's Rated Output voltage(R.O mV/V) written on the load cell label.


Input load cell Rated Output(mV/V) with key & key. Ex)In case of R.O is 1.987mV/V Input 1.98700

SPAN calibration is processing for 10 seconds.

After calculation, when span value shows, please input **F** key to save.

All of the calibration step is over.

- Pressing key means calcel, pressing **F** key means saving or going next.
- 4-2-3. Simulation calibration cause & treatment



It shows in case of $\frac{\text{load cell Rated Capa}}{\text{Division [Min unit]}} > 3,000$.

Ex) When Rated capa[Max capa] is 150kg , division[Min unit] cannot be under 0.05kg.




Amp. Gain is too big
Sig+/- wiring is connected wrongly.
The test weight is not loaded.

Amp. Gain is too small
Sig+/- wiring is connected wrongly.
The test weight is not loaded.

there is vibration on the load cell or load cell wire, the indicator cannot calculate calibration anymore.

It shows when you input wrong R.O
→ then please input again right R.O value, after recheck the label of load cell and retry the process.

How to change max capacity after finishing simulation calibration

After push CAL switch, "SEL-CAL" shows then press  key.
When "CAPA" displays input Max Capacity (which you need to use) and press  key to save it. Finally press  key until normal mode comes.

Due to some difference between "State output rate" and "Real Output rate" of load cell, there might be some weight difference after finishing calibration.
If you want to make more precise weighing process, please measure real output rate of load cell and input the measured value.
Then the weight measurement will be more precise than before.

Load cell 's Rated Capacity [R.C] in Simulation Calibration mode

Rated Capacity means the value written on the load cell label. It doesn't mean Max capa. Max capa & Rated Capa is not always same.
If you use 6 load cells and each Rated capa is 1tf.
→ Then the total Rated Capa is [6 x 1tf] → 6tf

SEWHACNM CO.,LTD. LOAD CELL SB210 type & LABEL



Load cell Rated Output voltage (R.O) mV/V

In case of that you use plural of load cells, input the average of all the load cells.

$$\text{Ex) } \frac{R.O1+R.O2+R.O3+R.O4}{\text{Total No.of load cells}} = \frac{1.987+2.023+1.993+2.120}{4} = 2.030 = \text{average R.O.}$$

Due to some variation between "State Rated Output" and "Real Rated Output" of load cell, there might be some weight difference after finishing calibration.
If you want to make more precise weighing process, please measure real Rated output of load cell and input the measured value. Then the weighing result will be more precise .

4-4. TEST Mode



TEST Mode can be used to test the basic state of the Keys, Analog board, Communication interface.

Before starting the TEST mode, please remove operating devices.

TEST mode	Key TEST	key 4times in 2seconds → →
	Analog TEST	key 4times in 2seconds → →
	Comm TEST	key 4times in 2seconds → →

4-4-1. Key TEST

SETUP

TEST

0

In normal mode press key four times in 2seconds.

Input key to enter TEST mode, input key .

Whenever you push each keys, you the matched No. will show.

: 1	: 2	: 3,	CA Switch: 4	: Esc
-----	-----	------	--------------	-------



If there is a key doesn't show any digit, it needs to be repaired

4-4-2. Analog Board TEST

SETUP

TEST

2 10375

0

In normal mode press key four times in 2seconds.

Input key to enter TEST mode, input key .

Under this mode, you can check analogue value to real digital value through Display. The last digital value can be fluctuated.

key is used to set ZERO, key is used to hide the cipher or to see he hidden cipher. Check the analog value by loading something on the plate.



If there is no change although pressing keys or loading some force on/in weighing part , it may something wrong with load cell, cable, connector or A/D board

This Analog test mode can be used to keep the balance at the wide platform.


4-4-3. Communication interface

SETUP	In normal mode press F key four times in 2seconds.
TEST	Input ZERO key to enter TEST mode,
Corr 1	Input F key to enter Communication interface TEST mode.



Connect with PC or other devices through serial interface and check the transmit and receive. At the normal operation, display will be blinked.

To test this mode, please use following “TESTING Protocol”.



4-5. F-FUNCTION Mode

Set-up means set the F-function and make optimal operation of SI 200 Indicator.

4-5-1. Key operation in F-FUNCTION Mode

ZERO ↑	TARE ←	F	NET GROSS
UP	LEFT	SAVE / ENTER / NEXT	ESC / CALCEL

4-5-2. F-FUNCTION Mode




In normal mode press **F** key four times in 2seconds.

Input **TARE** key

When "Func" displays, F-Function mode starts from 01.

Whenever you input **ZERO** key, Function increases 1 by 1.

● F11-01 → F11-08



Press **ZERO** key to increase F- value.


Press **ZERO** key 10 times until 11 shows up like left display.

Press **TARE** key until the cursor is under 1.

Press **ZERO** key to make 8.

Press **F** key to save the value.

● F01 → F45 directly



Press **ZERO** key to increase F- value.

Press **TARE** key one time so that the cursor is under 1.

Press **ZERO** key until 5 shows.

Press **TARE** key one time so that the cursor is under 1.





Press **ZERO** key when "1" is displays.

When F45 shows, input **F** key then F45-03 shows.

● Pressing **NET/GROSS** key means cancel, pressing **F** key means saving or going next.

4-6. F-FUNCTION list

■ Function setting

F-NO	SETTING	Select	Default
F01	Weighing Data Save Method selection	0~1	1
F02	Weight-Back up Mode selection	0~1	0
F03	Motion Band Range setting	1~99	5
F04	Zero Tracking Compensation Range setting	5~99	5
F05	Auto Zero Range setting	0~99	0
F06	Digital Filter setting	0~40	4
F07	Zero key Operation mode selection	0~1	1
F08	Zero key Operation Range selection : (-) value is same to (+)	0~6	2
F09	Zero key Operation Range selection : (-) value is same to (+)	0~3	2
F10	"Hold" Mode selection	0~2	0
F11	"STEADY" condition check time setting	0~99	3
F12	Display Up-Date speed setting	1~9	1
F13	Weight Display selection under "Unpass / OverLoad" condition	0~1	1
F14	 key &  key 's operation	0~2	0
F15	 key +  key Function	0~1	0
F18	Equipment No. setting – ID No. setting	1~99	1

■ Comm. Mode

F30	Parity Bit selection Mode	0~9	0
F31	Serial Communication Speed selection	0~9	2
F32	DATA Transference Method	0~2	1
F34	"Check-Sum" detection selection (Under F32-01 setting, only)	0~1	0
F35	Under Stream Mode select the way transmit data protocol/frame (basic port)	0~1	0
F36	DATA Transference Mode (Under F32-00 setting, only)	0~3	0
F37	DATA Transference Format (Under F32-00 setting, only)	0~3	0
F38	PRINT Mode selection (Under F32-02 setting, only)	0~2	0
F39	SERIAL Interface selection	0~1	0

■ Print Mode


F41	Weight Unit	0~2	0
F42	Print Format	0~1	0
F44	SUB/GRAND Total Data Delete selection	0~1	0
F45	Paper Withdraw Rate setting (After SUB/GRAND Total Print)	0~9	3
F46	Paper Withdraw Rate setting (After Continuous/Single Print)	0~9	3
F47	Printing Language	0~1	0
F49	Minus(-) symbol Print selection	0~1	0

■ Others

F80	EMPTY Range	0.010
F90	TIME(H,M,S) Check / Change (every 24Hours)	
F91	DATE Check / Change	
F95	SETUP Mode Password Key Setting / Change / Cancel	
F98	Program & Hard ware Version Check	

4-7. F-FUNCTION LIST





4-7-1. General Function Setting (“●” Factory default set value)









Weighing Data Save Method selection			
F01		0	Non-Save Mode (Weight Data & weighing counter)
	●	1	Save Mode (Weight Data & weighing counter)
Weight-Back up Mode selection			
F02	●	0	Normal Mode
		1	Weight Back up Mode (ZERO, TARE value)
Motion Band Range setting			
F03	5	01 ┆ 99	This is set “Steady” acceptable range of weighing part. If there is vibration on weighing part, you can set this function and reduce the vibration effect on weighing process. 1 : Weak vibration ~ 99 : Strong Vibration
Zero Tracking Compensation Range setting			
F04	5	0 ┆ 99	Due to external causes (Temperature, wind, and dust), there will be small weight difference, the Indicator will ignore the weight difference and display as Zero.
Auto Zero Range setting			
F05	00	00 ┆ 99	Within the “Auto Zero” range, weighing part is steady, indicator will display current weight as “Zero” If the weighing part is not “Steady”, indicator will display current weight. (Auto Zero Range : ± Set value + weight unit)
Digital Filter setting			
F06	4	0~40	0 (Weak vibration) ~ 40 (Strong Vibration)
Zero key Operation mode selection			
F07		0	Activate only under “Steady” condition
	●	1	Always activate
Zero key Operation Range selection : (-) value is same to (+)			
F08		0	Activated within 2% of Max. Capacity
		1	Activated within 5% of Max. Capacity
	●	2	Activated within 10% of Max. Capacity
		3	Activated within 20% of Max. Capacity
		4	Activated within 50% of Max. Capacity
		5	Activated within 100% of Max. Capacity
		6	There is no limit of Zero key operation range.
 If setting over than 10%, The display weight could be over than Load cell input signal or Max. Capacity and it may display “Cel-err” or incorrect weight value			

TARE key Operation Range selection : (-) value is same to (+)						
F09		0	Activated within 10% of Max. Capacity			
		1	Activated within 20% of Max. Capacity			
	●	2	Activated within 50% of Max. Capacity			
		3	Activated within 100% of Max. Capacity			
“Hold” Mode selection						
F10	●	0	Sample Hold : Hold current weight until “Hold Reset”			
		1	Peak Hold : Display Max. weight until inputting HOLDRESET			
		2	Average Hold : Hold average value for 5 seconds			
“STEADY” condition check time setting						
F11	3	0 └ 99	During the set time period, estimate weighing part’s “STEADY” condition and display. If you set small value, indicator will take “STEADY” fast, if you set value, indicator will take “STEADY” slowly.(0.5sec per set value)			
Display Up-Date speed setting						
F12	●	1	60/sec		6	6/sec
		2	30/sec		7	3/sec
		3	20/sec		8	2/sec
		3	15/sec		9	1/sec
		5	10/sec			
Weight Display selection under “Unpass / OverLoad”condition						
F13		0	Not Display Weight only UNPASS / -OL - / OVER is displayed.			
	●	1	Display Weight with UNPASS / -OL - / OVER with a flash			
TARE key & NET GROSS key ‘s operation						
F14	KEY		TARE key		NET GROSS key	
	●	0	TARE/TARE RESET		HOLD/HOLD RESET	
		1	TARE		TARE RESET	
		2	HOLD		HOLD RESET	
F key + TARE key Function						
F15	●	0	PRINT			
		1	TARE RESET			
Equipment No. setting – ID No. setting						
F18	01	1~99	ID No. setting with No. key. (01~99 settable)			

4-7-1. Communication Mode Setting


Parity Bit selection Mode			
F30	<input checked="" type="radio"/>	0	DATA Bit (8 Bit) STOP Bit (1 Bit) Parity Bit (Non)
	<input type="radio"/>	1	DATA Bit (8 Bit) STOP Bit (1 Bit) Parity Bit (Odd)
	<input type="radio"/>	2	DATA Bit (8 Bit) STOP Bit (1 Bit) Parity Bit (Even)
	<input type="radio"/>	3	DATA Bit (8 Bit) STOP Bit (2 Bit) Parity Bit (Non)
	<input type="radio"/>	4	DATA Bit (8 Bit) STOP Bit (2 Bit) Parity Bit (Odd)
	<input type="radio"/>	5	DATA Bit (8 Bit) STOP Bit (2 Bit) Parity Bit (Even)
	<input type="radio"/>	6	DATA Bit (7 Bit) STOP Bit (1 Bit) Parity Bit (Odd)
	<input type="radio"/>	7	DATA Bit (7 Bit) STOP Bit (1 Bit) Parity Bit (Even)
	<input type="radio"/>	8	DATA Bit (7 Bit) STOP Bit (2 Bit) Parity Bit (Odd)
	<input type="radio"/>	9	DATA Bit (7 Bit) STOP Bit (2 Bit) Parity Bit (Even)
Serial Communication Speed selection			
F31	<input type="radio"/>	0	2,400bps
	<input type="radio"/>	1	4,800bps
	<input checked="" type="radio"/>	2	9,600bps
	<input type="radio"/>	3	14,400bps
	<input type="radio"/>	4	19,200bps
	<input type="radio"/>	5	28,800bps
	<input type="radio"/>	6	38,400bps
	<input type="radio"/>	7	57,600bps
	<input type="radio"/>	8	76,800bps
	<input type="radio"/>	9	115,200bps
DATA Transference Method			
F32	<input type="radio"/>	0	Simplex Mode / Stream Mode
	<input checked="" type="radio"/>	1	Duplex Mode / Command Mode
	<input type="radio"/>	2	PRINT Mode
“Check-Sum” detection selection (Under F32-01 setting, only)			
F34	<input checked="" type="radio"/>	0	Check-Sum Not Use
	<input type="radio"/>	1	Check-Sum Use
Under Stream Mode select the way transmit data protocol/frame (basic port)			
F35	<input checked="" type="radio"/>	0	Transmit by Protocol
	<input type="radio"/>	1	Transmit by frame (in case of using specific utility)
In case of “Transmit by frame” & under 14,400bps setting(F31), the speed of system will be slow.			

DATA Transference Mode (Under F32-00 setting, only)					
F36	●	0	Always		
		1	Single time data transference, Whenever the weight is steady over Empty range.		
		2	Single time data transference, at first steady point, over Empty range.		
		3	Data transference, Whenever INPUT “Print” key input		
DATA Transference Format (Under F32-00 setting, only)					
F37	●	0	Format 1 (recommended when use external display)		
		1	Format 2. (Format 1 + ID No.)		
		2	Format 3. (recommended when connecting to PLC or PC)		
		3	CAS Format		
PRINT Mode selection (Under F32-02 setting, only)					
F38	●	0	Manual PRINT	When inputting  Key +  Key	
		1	Auto PRINT	When inputting  Key +  Key	At the first Steady point over “EMPTY” range
		2			Every Steady state at over “EMPTY” range
SERIAL Interface selection					
F39	●	0	RS-232C. (Side Switch UP)		
		1	RS-485 (Side Switch DOWN)		
● Print Mode Setting					
Weight Unit					
F41	●	0	Kg		
		1	g		
		2	t		
Print Format					
F42	●	0	Continuous Print - Serial No. and Weight will be printed continuously.		
		1	Single Print - Date, Time, S/N, ID No. Weighing Data will be print		
SUB/GRAND Total Data Delete selection					
F44	●	0	Not deleted (= manual Delete mode)		
		1	Automatically Deleted.-After print out SBU/GRAND Total.		
Paper Withdraw Rate setting (After SUB/GRAND Total Print)					
F45	3	0~9	Whenever set value increased as 1, then 1 line will be added.		


Paper Withdraw Rate setting (After Continuous/Single Print)			
F46	3	0~9	Whenever set value increased as 1, then will be added.
Printing Language			
F47	●	0	KOREAN
		1	ENGLISH
Minus(-) symbol Print selection			
F49	●	0	Print minus(-) symbol, if the weight is minus(-).
		1	Ignore minus(-) symbol
4-7-2. Other Setting Mode			
EMPTY Range			
F80	0.010	You can set "EMPTY" Range.	
		Ex) 0.0 10 setting : When Net Zero, "Zero" status lamp is ON. 200 setting : Under "200", "Zero" Status lamp is ON.	
TIME(H,M,S) Check / Change (every 24Hours)			
F90	Check Current time data or you can Change to new time		
DATE Check / Change			
F91	Check Current Date data or you can Change to new date		
SETUP Mode Password Key Setting / Change / Cancel			
F95	Setting Password	When "I" displays input password you want to use with  key &  as four digit. When "2" displays input the 4-digit password again to confirm it as your password.	
	Change Password	When "P-LJ" shows input your password. When "I" displays input password you want to use with  key &  as four digit. When "2" displays input the 4-digit password again to confirm it as your password.	
	Delete Password	If you set password with  key, the password is canceled.	
You cannot enter SETUP & Calibration mode without password. Memorize it.			
Password is set with only  key &  key. If  key is used password is canceled.			
Program & Hard ware Version Check			
F98	Check the Program & Hard ware version Ex) "100 1.04" means H/W : ver.1.00 & S/W : ver.1.04		

5. INTERFACE

5-1. Serial Interface RS – 232C (F39-00 setting – Side switch up - standard)



5-2. Serial Interface RS-485 (F39-01 setting – Side switch down)



Serial communication interface is sensitive to electric noise.

Install isolated place from Power cable or other electric cables and wires, and please use shielded cable for better performance.

5-3. Data Format

5-3-1. Data Format1 : without ID No. (Refer F-37)

Header1			Header2			Weight Data 7 byte							Unit				
		,			,	+/-								k	g	CR	LF

Header1	Header2
OL : OVER LOAD	NT : NET-WEIGHT(Tare is not set)
ST : STEADY	GS : when setting TARE
US : UNSTEADY	

5-3-2. Data Format2 (With ID No. Refer F- 18, F37-01)

ID Number		Header1		Header2		Weight Data 7 byte							Unit			
		,			,								k	g	CR	LF


Header1	Header2
OL : OVER LOAD	NT : NET-WEIGHT(Tare is not set)
ST : STEADY	GS : when setting TARE
US : UNSTEADY	

5-3-3. Data Format3 : ID No. + State(Refer F-18, F37-02)

STX	ID No.	Header1	Header2	Weight Data 7 byte							Decimal Point	
02h				W	+/-						P	03h

Header1	Header2
O : OVER	G : Gross weight
S : STEADY	N : Net weight
U : UNSTABLE	

5-3-4. CAS Format (22byte)



LAMP DISPLAY

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	0	1	1	1	1	1	1
1	STEADY	1	Hold	Print	Gross Weight	TARE	ZERO

Header1	Header2
OL : OVER LOAD	NT : GROSS weight
ST : STEADY	GS : Net weight
US : UNSTEADY	


5-4. Command Mode (F32-01 setting)



Under "Command Mode", Indicator will recognize the receipt of Order based on 02h(Header) and 03h(END) signal, and transfers ACK/ NAK).

The command to send the Indicator must be HEX.

In case of ASCII code, it has to be converted to HEX to transmit.



※Although wrong value is transmitted, the communication format is matched, then ACK is transmitted.

5-4-1. Read Command

The min. interval of read command is 100ms. (In case of check-sum 150ms)

Current Weight data																				
PC → SI200 Read	ASCII	STX ID(2Byte) RCWT ETX																		
	HEX	02 30 31 52 43 57 54 03																		
SI 200 → PC Respond	STX ID RCWT State1(1byte) State2(1byte) P decimal point(1byte) +/- (1byte) Current weight(7byte) Weight unit(2byte) ETX																			
	State1 : O(Over load) , S(Steady), U(Unsteady) State2 : N(Net weight), G(Gross weight)																			
Ex) Steady(S), TARE not used(N), 0.000kg																				
STX ID R C W T S N P 3 + 0 0 0 0 0 0 0 0 k g ETX																				
02h 30h 31h 52h 43h 57h 54h 53h 4Eh 50h 33h 2Bh 30h 30h 30h 30h 30h 30h 30h 6Bh 67h 03h																				
Indicator memory data																				
PC → SI200 Read	ASCII	STX ID(2Byte) RCWD ETX																		
	HEX	02 30 31 52 43 57 44 03																		
SI 200 → PC Respond	STX ID RCWD P decimal point(1byte)DATE(6byte) TIME(6byte) the no. of weighing (6byte) +/- TARE(7Byte) +/- current weight(7byte) unit(2byte) ETX																			
Ex) DATE : Aug 12 th ,2009, TIME : 12:00:00, the no. of weighing : 10, TARE : 2.000kg, current weight : 3.000kg																				
STX ID R C W D P 3 0 9 0 8 1 2 1 2 0 0 0 0																				
02h 30h 31h 52h 43h 57h 44h 50h 33h 30h 39h 30h 38h 31h 32h 31h 31h 30h 30h 30h 30h																				
0 0 0 0 1 0 + 0 0 0 2 0 0 0 + 0 0 0 3 0 0 0 ETX																				
30h 30h 30h 30h 31h 30h 2Bh 30h 30h 30h 32h 30h 30h 30h 2Bh 32h 30h 30h 33h 30h 30h 30h 03h																				
Grand Total																				
PC → SI200 Read	ASCII	STX ID(2Byte) RGRD ETX																		
	HEX	02 30 31 52 43 57 44 03																		
SI 200 → PC Respond	STX ID RGRD P decimal point(1byte)Accumulated S/N count (6byte) Accumulated weight(10byte) weight unit(2byte) ETX																			
Ex) the no. of weighing : 10 , Accumulated Weight : 10.000kg																				
STX ID R G R D P 3 0 0 0 0 1 0 0 0 0 0 1 0 0 0 0 ETX																				
02h 30h 31h 52h 47h 52h 44h 50h 33h 30h 30h 30h 30h 31h 30h 30h 30h 30h 31h 30h 30h 30h 30h 03h																				
Current Time																				
PC → SI200 Read	ASCII	STX ID(2Byte) RTIM ETX																		
	HEX	02 30 31 52 54 49 4D 03																		
SI 200 → PC Respond		STX ID R DAT Current Date(6byte) ETX																		
STX ID R T I M 1 2 0 0 0 0 ETX																				
02h 30h 31h 52h 54h 49h 4Dh 31h 32h 30h 30h 30h 30h 03h																				
Ex) Time : 12:00:00																				

Current Date																		
PC → SI200 Read	ASCII	STX ID(2Byte) RDAT ETX																
	HEX	02 30 31 52 44 41 54 03																
SI 200 → PC Respond		STX ID RDAT Current Date(6byte) ETX																
Ex) Date : Aug 12 th ,2009		STX	ID	R	D	A	T	0	9	0	8	1	2	ETX				
		02h	30h	31h	52h	41h	41h	54h	30h	39h	30h	38h	31h	32h	03h			
TARE data																		
PC → SI200 Read	ASCII	STX ID(2Byte) RTAR ETX																
	HEX	02 30 31 52 54 41 52 03																
SI 200 → PC Respond		STX ID RTAR P decimal point(1byte) +/- (1byte) TARE value(7byte) ETX																
Ex) TARE : 2.000kg		STX	ID	R	T	A	R	P	3	+	0	0	0	2	0	0	0	ETX
		02h	30h	31h	52h	54h	41h	52h	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h



Recommended Interval of READ COMMAND is min.60ms, 70ms is recommended, under 9600bps setting.

Min.60ms is required between each Read Command(under RCWD)

Min. interval is changed when data's length & speed are changed.

Min Interval : 20ms under 2400bps(RCWD)

Min Interval : 40ms under 115200bps (RCWD)

5-4-2. Write Command

Recommended Comm. Interval of WRITE COMMAND is 150ms You have to guarantee Min. 200ms interval between two different commands.(In case of Check-Sum, 250ms)

Zero (same as ZEROkey)			
PC→ SI200 Write		SI 200 → PC Respond	
ASCII	HEX	OK	Error
STX ID(2Byte) WZER ETX	02 30 31 57 5A 45 52 03	STX ID ACK ETX	STX ID NAK ETX
TARE			
PC→ SI200 Write		SI 200 → PC Respond	
ASCII	HEX	OK	Error
STX ID(2Byte) WTAR ETX	02 30 31 57 54 41 52 03	STX ID ACK ETX	STX ID NAK ETX
TARE reset			
PC→ SI200 Write		SI 200 → PC Respond	
ASCII	HEX	OK	Error
STX ID(2Byte) WTRS ETX	02 30 31 57 54 52 53 03	STX ID ACK ETX	STX ID NAK ETX

HOLD																	
PC→ SI200 Write		SI 200 → PC Respond															
ASCII	HEX	OK	Error														
STX ID(2Byte) WHOL ETX	02 30 31 57 48 4F 4C 03	STX ID ACK ETX	STX ID NAK ETX														
HOLD reset																	
PC→ SI200 Write		SI 200 → PC Respond															
ASCII	HEX	OK	Error														
STX ID(2Byte) WHRS ETX	02 30 31 57 48 52 53 03	STX ID ACK ETX	STX ID NAK ETX														
PRINT																	
When transfer format, “F46 : plus line” and “F34 : checksums are not applied.																	
PC→ SI200 Write		SI 200 → PC Respond															
ASCII	HEX	OK	Error														
STX ID(2Byte) WPRT ETX	02 30 31 57 50 52 54 03	STX ID ACK ETX	STX ID NAK ETX														
Delete grand total																	
PC→ SI200 Write		SI 200 → PC Respond															
ASCII	HEX	OK	Error														
STX ID(2Byte) WGTC ETX	02 30 31 57 47 54 43 03	STX ID ACK ETX	STX ID NAK ETX														
Date setting																	
PC→ SI200 Write		SI 200 → PC Respond															
STX ID(2Byte) WDAT date (6byte) ETX	OK		Error														
	STX ID ACK ETX		STX ID NAK ETX														
<div>STX ID W D A T 0 9 0 8 1 2 ETX</div> <div>Ex) 12th August <table><tr><td>02h</td><td>30h</td><td>31h</td><td>57h</td><td>44h</td><td>41h</td><td>54h</td><td>30h</td><td>39h</td><td>30h</td><td>38h</td><td>31h</td><td>32h</td><td>03h</td></tr></table></div>				02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h
02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h				
Time setting																	
PC→ SI200 Write		SI 200 → PC Respond															
STX ID(2Byte) WTIM time (6byte)ETX	OK		Error														
	STX ID ACK ETX		STX ID NAK ETX														
<div>STX ID W T I M 1 2 0 0 0 0 ETX</div> <div>Ex)time : 12:00:00 <table><tr><td>02h</td><td>30h</td><td>31h</td><td>57h</td><td>54h</td><td>49h</td><td>4Dh</td><td>31h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td></tr></table></div>				02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h
02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h				



The interval of Print command is min 100ms, the min interval of Print total weighing data is min 300ms, When you use both command, you 'd better enough interval between them.

5-5. Command Mode Example

5-5-1. Read Command Example

Ex.) Current Weight data (RCWT), ID No. : 01, Current Weight : 7,000kg

1) STX ID NO. RCWT ETX Without CHECK SUM (F34-00)

- PC → SI200 Read command

STX	ID No.	R	C	W	T	ETX
02h	30h	31h	52h	43h	57h	54h
03h						

- SI200 → PC Respond

STX	ID No.	R	C	W	T	S	N	P	3	+	0	0	0	7	0	0	0	ETX
02h	30h	31h	52h	57h	52h	54h	53h	4Eh	50h	33h	2Bh	30h	30h	30h	37h	30h	30h	30h
03h																		03h

2) STX ID RCWT ETX With CHCEK SUM (F34-01)

- PC → SI200 Read command

STX	ID No.	R	C	W	T	Check Sum	ETX
02h	30h	31h	52h	43h	57h	54h	41H
03h							36H
03h							03H


- SI200 → PC Respond

STX	ID No.	R	C	W	T	S	N	P	3	+	0	0	0	7	0	0	0	Check Sum	ETX
02h	30h	31h	52h	57h	52h	54h	53h	4Eh	50h	33h	2Bh	30h	30h	30h	37h	30h	30h	30h	5 A
03h																		35h	41h
03h																		03h	03h


5-5-2. Write Command Example

Ex) Set the time as 12:00:00, ID number :1

1) STX ID WTIM 120000 ETX Without CHECK SUM(F34-00)



2) STX ID WTIM 120000 ETX With CHECK SUM(F34-01)

**How to get CHECK SUM**

All Read/Write command must be use "HEX CODE"..

How to Calculate Check sum.

- Sum the value from "STX" to "ETX" and converts to ASCII(2byte) and transfer.
Convert the Sum value(HEX) to ASCII and transmit(28byte) .

ex) The sum HEX value from STX to ETX(02,30,31,52,43,57,54,03) is 1A6h.

Then, divide 1A6h by 100h(1A6h/100h). the rest of result is A6h.

Calculated remainder value is A6h, then convert A6h to ASCII, 41(A), 36(6), and transfer.

5-6. Print interface

It can be connected with all kinds of Serial interface printer, but the printing format is already programmed and fixed with our SE7200/7300 model.

Printing Format (F32-02 under setting)

	KOREAN (F47-00)	ENGLISH (F47-01)
Continuous Print Format F42-00	<pre> ===== 날짜 : 2011-05-10 시간 : 18:00:10 순번 중량 1 + 1.330kg 2 + 5.350kg 3 + 1.380kg 4 + 2.330kg ===== </pre>	<pre> ===== DATE : 2011-05-10 TIME : 18:00:10 COUNT WEIGHT 1 + 1.330kg 2 + 5.350kg 3 + 1.380kg 4 + 2.330kg ===== </pre>
Single Print Format F42-01	<pre> ===== 날짜 : 2011-05-10 시간 : 18:00:10 순번 중량 3 + 1.380kg ===== 날짜 : 2009-05-10 시간 : 18:00:10 순번 중량 4 + 6.230kg ===== </pre>	<pre> ===== DATE : 2011-05-10 TIME : 18:00:10 COUNT WEIGHT 2 + 5.350kg ===== DATE : 2009-05-10 TIME : 18:00:10 COUNT WEIGHT 3 + 1.280kg ===== </pre>
Grand Total Print F44-00	<pre> ===== 총 계 날짜 : 2011-05-10 시간 : 18:00:10 계량횟수 : 10 누적중량 : 258.145kg ===== 총계 삭제 ===== </pre>	<pre> ===== TOTAL DATE : 2011-05-10 TIME : 18:00:10 COUNT : 10 TOTAL WEIGHT : 258.145kg ===== TOTAL DELETE ===== </pre>

6. Error & Treatment

6-1. Load Cell Installation

Error	Cause	Treatment	Remark
Unstable display	1) Load cell problem 2)Load cell isolation resistance error 3)Contact, touch problem 4) Summing box problem	1) Measure input or output resistance of Load cell. 2) Measure Load cell isolation resistance	1. Input Resistance of “EXC+” and “EXC-” is about 400Ω. ±3 2. Output Resistance of “SIG+” and “SIG-” is about 350Ω. ±3.5 3. Isolate Resistance is more than 100Ω
Weight doesn't return to “Zero”	1) Load cell problem 2) Load cell wiring contact problem	1) Check Load cell connection 2) Measure Load cell Resistance	
Display under(-) zero although you load something	the switched Load cell output wires (SIG+,SIG-)		Load cell Check Load cell connection Check Calibrate weight again
right after calibration display “UNPASS”	Load cell broken or Indicator connection Error		
	Power was “ON” when some weight is on the load cell.		
display “-OL -”“OVER” (OVER LOAD)	1) Load cell broken or Indicator connection Error 2) Loading over than Max. Capacity.	1) Load cell or connection Check 3) Remove the loaded weight 4) Calibrate again	Double TARE(F key+ TARE key) is applied too many. (over limit capa)

6-2. Calibration Process

Display	Cause
Err-1	It shows in case of $\frac{\text{Rated capa [Max Capa]}}{\text{Division [Min unit]}} > 20,000$. Ex) Rated capa[Max capa] is 20,000 , division[Min unit] cannot be under 1
Err-4	It shows when the Test weight > Rated capa[Max capa] → Then please re-input right value again. The more heavy test weight makes the more accurate measurement.
Err-5	It shows when the Test weight < 10% of Rated capa[Max capa] → Then Please re-input right value again.
Err-6	Amp. Gain is too big / Sig+/- wiring is connected wrongly. / The test weight is not loaded.
Err-7	Amp. Gain is too small / Sig+/- wiring is connected wrongly. / The test weight is not loaded.
Err-8	Under "F-function" model, set value is appropriate.
Err-A	there is vibration on the load cell or load cell wire, the indicator cannot calibrate anymore.

6-3. Digital Weighing Indicator

Display	Cause	Treatment
CELL-Err OR OVER	1. Load cell Error 2. Load cell cable Error 3. Load cell connection Error 4. A/D Board Error 5. If Analogue value is over 1,040,000. ※ When weigh “-” value, If it is over set max capa, “OVER” is displayed. Ex) Even though set max capa is “100” and it is over “-100”, “OVER” is displayed.	1. Under “TEST” mode 1, check analogue value. If you cannot get any analogue value or there is no change although adding load, please check load cell, load cell cable, connection conditions first. 2. Replace another load cell, and check the indicator condition. If you have same problem, please replace new indicator and check A/D board error. 3. Try to connect the indicator’s A/D with the other indicator. 4. Check the power and load cell connection of terminal. ※ In this situation ZERO key & PRINT key are not activated.
UNPASS	1. Power is ON, when some materials are on weighing part. ※ Under “Normal Mode”, if there are more than 20% loading of Max. capacity, “UNPASS” display will be appeared and indicator will stay until removing the load. ※ Setting Back-up mode it can memory empty value, and it becomes set value without displaying” Un-pass”)	1. If you set “Normal Mode”, please check weighing part empty or not before turn on the power. If there are some materials in/on weighing part, please remove those materials and turn on the power. 2. Please try to set F02-01(Back-up) mode so that the indicator can remember first empty value.
SEt	EEPROM problem	Please contact the distributor or Head Office.
HALt	H/W Problem	
St-Err	The Error about Time	

WARRANTEE CERTIFICATION

This product is passed "Sewhacnm's strict quality test.
If there is defect of manufacturing or abnormal detection within warrantee period,
please contact our Agent or Distributor with this Warrantee certificate.
Then, we will repair or replace free of charge.

WARRANTEE CLAUSE

1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date
2. Warrantee Exception Clause
 - Warrantee period is expired.
 - Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm's permission.
 - Any kinds of Mal-function, Defection, or External damage, caused by operator
 - Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent.
 - Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this manual.
 - Any kinds of Mal-function, Defection caused by "Force Majeur", like Fire, Flood.
 - Without presentation of this "Warrantee Certification".
3. Other
 - Any kinds of "Warrantee Certification" without authorized Stamp is out of validity

SEWHACNM Co.,Ltd. #504-302, 397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea Made in KOREA Website : http://www.sewhacnm.co.kr , Email : sales@sewhacnm.co.kr	Product	Digital Weighing Indicator
	Model	SI 200
	Serial No.	
	AUTHORIZING STAMP	