

CE

Approved for Digital
Weigh Indicator

Digital Weighing Indicator SI 300

Instruction Manual



 **SEWHACNM**
주식회사 세화씨엔엠

CONTENTS

1. Before Installation	-----	3 Page
2. Introduction	-----	4 Page
3. Specification	-----	5 Page
3-1. Specification	-----	5 Page
3-2. Front Panel	-----	6 Page
3-3. Connector	-----	8 Page
3-4. Composition	-----	8 Page
4. Installation	-----	9 Page
4-1. Dimension & Cutting Size	-----	9 Page
4-2. Installation Components	-----	10 Page
5. Set up	-----	11 Page
5-1. Set Up mode	-----	11 Page
5-2. TEST Weight Calibration Mode	-----	12 Page
5-3. Simulating Calibration Mode	-----	14 Page
5-4. F-FUNCTION Setting	-----	16 Page
5-5. Test Mode	-----	22 Page
6. Interface	-----	24 Page
6-1. Serial Interface	-----	24 Page
6-2. Serial Print	-----	33 Page
7. Error & Treatment	-----	34 Page
Warrantee Certificate	-----	37 Page

1. BEFORE INSTALLATION

Caution / Warning Marks



This mark warns the possibility to arrive death or serious injury in case of wrongly used.



This mark cautions the possibility to arrive serious human body injury or product lose in case of wrongly used.

Copy Rights

1. All Right and Authority for this Manual is belonged to SEWHA CNM CO., LTD.
2. Any kinds of copy or distribution without permission of SEWHA CNM CO., LTD. will be prohibited.
3. This manual may be changed as the version is upgraded, without previous notice.

Inquiries

If you have any kinds of inquiries for this model, please contact your local agent or Head Office.

Head Office : SEWHA CNM CO., LTD.

Website : <http://www.sewhacnm.co.kr>

Email : sales@sewhacnm.co.kr

2. INTRODUCTION

Introduction

Thank you for your choice of this SI300 Industrial Digital Weighing Indicator.

This SI300 model is high-performance weighing Indicator.

Please review and learn this instruction Manual and enjoy your process efficiency with "SI 300" Weighing Indicator.



Cautions

1. Don't drop on the ground and avoid serious external damage on item.
2. Don't install under sunshine or heavy vibrated condition.
3. Don't install place where high voltage or heavy electric noise condition.
4. When you connect with other devices, please turn off the power of item.
5. Avoid from water damage.
6. For the improvement of function or performance, we can change item specification without previous notice or permission.
7. Item's performance will be up-dated continuously base on previous version's performance.

Features

1. SI 300 model is the standard 1/8 DIN SIZE and compact enough, so it is easy to install.
 2. It has wide range of DC Input.
 3. Front panel is covered with Polycarbonate film, strong against dust and water.
 4. RS-422/485 serial port standard installed,
-

3. SPECIFICATION

3-1 Specification

Content		Specification	
Performance	External Resolution	1/20,000	
	Internal Resolution	1/2,097,152 ($\pm 1,048,576$)	
	Input Sensitivity	0.1 μ V/V	
	Max. Signal Input Voltage	3.0 mV/V	
	Load cell Excitation	DC +5V	
	A/D Conversion Method	Sigma-Delta	
	Decimal Point	0, 0.0, 0.00, 0.000	
	Drift	Offset	10PPM/ $^{\circ}$ C
		Span	10PPM/ $^{\circ}$ C
	Linearity		0.001% of Full Scale
Analogue Sampling(sec)		60times / sec	
Environment	Operating Temperature Range	-10 $^{\circ}$ C ~ +40 $^{\circ}$ C [14 $^{\circ}$ F ~ 104 $^{\circ}$ F]	
	Operation Humidity Range	40% ~ 85% RH, Non-condensing	
Function	Calibration Mode	Test Weight Calibration Mode Simulation Calibration Mode	
	Display	7segment 6 digit, 1 inch Red Color FND	
	Key Pad	6EA Key including CAL key	
Comm	Serial Interface	Data Transference Command Mode Serial Printer Mode	
Power	AC100V ~ AC 240V (50/60Hz)		
Size	190mm(W) x 124mm(H) x 122mm(D)	Weight : 2.0kg	

3-2. Front Panel

3-2-1 Front Panel (Display / Key Pad)



3-2-2. State Lamp

Display	Meaning
STEADY	When the weight is "STEADY", Lamp is ON.
ZERO	When the current weight is "ZERO", Lamp is ON.
TARE	"TARE" function is set, Lamp is ON.
HOLD	"HOLD" function is set, Lamp is ON.
TxD	When the Indicator transmits Serial communication data (Print data), Lamp is ON.
RxD	When the Indicator receives Serial communication data, Lamp is ON.
F	When the "F" key is working, Lamp is ON.

3-2-3. Key Operation

	<ol style="list-style-type: none"> 1. Normal Mode : Make Weight value as Zero. (F07, F08 setting) 2. Calibration Mode : Cancel the value or move to previous step.
	<ol style="list-style-type: none"> 1. Normal Mode : Set the TARE Function .(F09 setting) 1 time input : "TARE", 2 times input : "TARE Reset" (When "HOLD" or weight value is ZERO, then this key doesn't work.) 2. Calibration Mode : Move to left 3. F-Function setting : Move to left 4. Test Mode 1 : Analog value check mode
	<ol style="list-style-type: none"> 1. To set the "HOLD" Function (refer F10) [1st input : "HOLD", 2nd input : "HOLD Reset"] 2. Calibration Mode : Move to right 3. F-Function setting : Move to right 3. Under "SETUP" Mode, Enter into the "Calibration" Mode. 4. Test Mode 1 : Analog Variation value check mode
	<ol style="list-style-type: none"> 1. Normal Mode : Print out (refer F38, F32) 2. Calibration Mode : Increase set value 3. F-Function setting : Increase set value 4. Set up Mode : Enter Test Mode. <p>※ If the printer is installed, under "F01-01 setting, when you press this key the current valued is increased. And the current weight is saved and print out, altogether. (Refer to CH.5-4)</p>
	<ol style="list-style-type: none"> 1. Press this key 4times, within 2secs, enter "SET-UP" mode. 2. F-Function setting : Save the value go to next step

● Setup Mode :It is a mode can SET UP the calibration, Function of SI300. (refer to CH5. SET UP)

3-2-4. Hot key (with F key)

	<p>Continuous "TARE" setting (From the second TARE setting, use this key)</p>
	<p>If the Printer is installed, You can print out the "Grand-total data". (GRAND-total data can be checked though Print output).</p>
	<p>Manual delete the grand total data</p>

 Max. accumulated weighing count : 999,999times Over 999,999times → return to "0" time
 Max. accumulated weight display : 999999999 (g, kg, ton)
 Over 999,999,999 (g, kg, ton) → return to "0" (g, kg, ton)

SI 300

Wall mounting / Desk type DIGITAL WEIGHT INDICATOR

3-3. Connector



LOAD CELL					RS-232C			CURRENT LOOP		OFF
EX+	EX-	SIG+	SIG-	SH	RxD	TxD	GND	C/L	C/L	ON


3-4. Composition

SI 300	AC Power Cable	Side Bolt	Terminal Pin	Manual
				

4. INSTALLATION

4-1. External Dimension & Cutting Size


External Dimension (unit: mm)



4-2 Load cell Installation

Load Cell Wire Connection (In case of SEWHACNM's Load cell)

It depends on the manufacturer of load cell, please check the specification.



-----Sewhacnm Co.,Ltd. Load cell & wire color----

※ Load cell wire color can be changed without prior notice.

Load Cell Installation

1. You can connect Max. 8pcs of same capacity Load cells at once. (350 Ω)
2. You have to make horizontal balance on the ground.
3. If you install more than 2pcs of load cells, use Summing box and adjust output signal difference as minimum. It can make wrong weighing process caused by each load cell's variation.
4. If there is some temperature difference around Load cell, it can cause wrong weight measurement.
5. Don't do Welding job or Arc discharge around installation place. But, there is no choice, please disconnect power cable and Load cell cable.
6. If you measure static electricity material, please make earth between down part and up part of Load cell.
7. Under set up the Load cell, if EXC+ and EXC- have a short circuit, It may cause damage in the indicator.(specially analogue board)
8. If you connect other wires to Load cell terminal wrongly, it may cause damage in the analogue board.
9. Before connecting the load cell cable you have to power off and be sure to connect the cable to the terminal correctly.
10. Do not weld near the load cells , Indicators or other devices.

5. SET-UP

5-1. Adjusting "ZERO" Balance (Calibration)

Adjust weight balance between "Real weight" on the load cell (Weight Part) and "Displayed weight of Indicator". When you replace LOAD CELL or Indicator, you have to Calibrate process once again.

(When you start calibration mode, TARE, HOLD & PRINT function is reset.)

 Before processing calibration, please warm up the indicator during 15 min to guarantee more preciseness.

Calibration Key				
				
CANCEL/BACK	Move to left	Move to right	Increase set value	SAVE/NEXT

● To Go Each Mode

Calibration	Weight Calibration	CAL key → 
	Simulation Calibration	CAL key →  → 
F-FUNCTION Mode		 key 4 times → 
Test Mode	Analog Value	 key 4 times →  → 
	Serial interface	 key 4 times →  → 
	Key test	 key 4 times →  →   :1,  :2,  :3,  :4,  :ESC

- Entering  means ESC/UPPER step, Entering  means SAVE/NEXT Step.
- Default is no password. Displaying "P-W" means the password is activated. Please input your pass word.

5-2 Test Weight Calibration Mode (Using test weight)

5-2-1. Starting Test Weight Calibration Mode



When "CALIBR" is displayed, press  key. Then Test Weight Calibration Mode will be started.

5-2-2. Max using capacity




When "CAPA" is showed, input max capacity with keys & Press  key to save the data & move to next step.



Ex) When max capacity : 20kg, Minimum division : 0.001kg

Input '20' and press  key to save and go to the next step.

5-2-3. "Decimal Point" and "Digit / Division" Value



After "DIVI" is displayed



Select Decimal point & division with  &  key.

Ex) When Max capacity : 20kg, Min division : 0.001kg.

Input '0.001' and press  key to save and move to next step.



Max Decimal point will be 0.001, and digit can be selectable among 1, 2, 5, 10, 20, 50.

Digit and Decimal point must be fulfill the below condition.

(Division value /Max capacity value) cannot be less than 1/20,000.

If the division is so small compare with max capacity,

Error message " Err 01 " will be displayed and move back to "CAPA" step again.

5-2-4. Measuring the "DEAD" Weight of Weighing Scale.



When "DEAD" is displayed, press  key, then indicator will calculate Dead weight of scale part automatically.



Indicator will search "DEAD weight" during 10~20 seconds to find the best condition.

※ To guarantee the preciseness, DEAD weight calculation (CAL00~CAL09) will be operated twice when resolution (Division value /Max capacity value) is less than 1/10,000.



In this step, if there is some force or vibration on weighing scale, and unstable condition will be continued, "ErrorA" will be display, and "DEAD value" will not be calculated.

Please remove all the force or vibration and process it again.

5-2-5. Input Test Weight value and Calculate SPAN value.



If "SPAN" is displayed, input "Test Weight" capacity and press  key.



For example, when the weight of test weight is 5kg, input 5.000



When "UP" is displayed, load your test weight on the scale (weigh bridge) and press  key.



Calculate Span value during 10 ~20 secs, automatically.

※ To guarantee the preciseness, SPAN calculation (CAL00~CAL09) will be operated twice when resolution (Division value /Max capacity value) is less than 1/10,000.



After calculation, span value will be displayed on the display. Then press  key. ※This span value is not a weight value.



When " END" is displayed and calibration is completed.

5-3. Simulation Calibration Mode(Calibrate without Test weight)

With this "Simulation Calibration Mode" you can make simple calibration without any "TEST weight"

This calibration mode uses "Load cells' max capacity" and "Max Output Rate(mV)", so the weight adjustment degree might be less than "Test weight Calibration".

The guaranteed resolution of this "Simulation Calibration" is 1/3,000.

5-3-1. Simulation Calibration Mode Start

CAL 1br

After remover CAL bolt, press the CAL lock button.

When "CALIBR" displays, press  key,

Then Test Weight Calibration Mode starts.

S-CAL

After displaying "S-CAL", press  key and input the Max using capacity with direction keys.

5-3-2. Setting "Capacity of Load Cell"

CAPA

After "CAPA" is displayed, Check the max Capacity of your load cell.
(Refer the label on the load cell, or test report.)

3

Ex) In case of Rated capacity : 3t, Min division : 0.001t(1kg), input 3.

And press  key to save and go to the next step.



In case of multiple pieces of load cells are installed, make sum of each load cell's capacity and make setting with max capacity. EX) There are 4pcs of load cells, and each load cell's Max capa is 1,000kg.

Then, total Max Capacity will be 4,000kg(1,000 x 4) and you have to input 4,000.

5-3-3. Setting "Digit / Division" value

d i u i

After "DIVI" is displayed select Decimal point with  key.

0.001

Select Decimal point & division with  &  key.

Ex) In case of Max using capacity : 3tf, Min division : 0.001t(1kg).

Input 0.001 . Finally press  key to save and move to next step.

5-3-4. Measure the "DEAD Weight" of Weighing Scale.

dEAd	When "DEAD" is displayed, press  key with empty scale. Then the indicator starts to measure and find optimal "Dead weight value of Scale" automatically.
CAL-0	It takes 10sec or 20sec to get the best situation.

5-3-5. Input Max. Output (Rated Output Voltage / mV)

r n U	After "mV" is displayed, Check the Rated output value of Load cell. (Refer to the load cell label, or Test Report) .
2.00000	Ex) Load cell rated output 2.0mV/V
bAd	If input wrong value, there will display "BAD", please go back to <i>Setting "Capacity of Load Cell"</i> . After recheck the label of load cell and retry the process.
done	After finishing calculation, calculated "Span value", "DONE" will be displayed.
0.62923	Now, the Simulation Calibration is done,
End	Press  key to complete the calibration process.



In case of multiple pieces of load cells are connected, the rated output will be same as single load cell's. (Because plural load cells are connected with parallel connection, the sum of rated output voltage is same as single load cell's rated output)

※Due to some variation between "State output rate" and "Real Output rate" of load cell, there might be some weight difference after finishing calibration.

If you want to make more precise weighing process, please measure real output rate of load cell and input the measured value.

This Simulation calibration mode uses "Load cells' max capacity" and "Max. Output Rate(mV)", so the weight adjustment degree might be less than "Test weight Calibration". ***The guaranteed resolution of this "Simulation Calibration" is 1/3,000.***

5-4. F-FUNCTION Setting

This is the Menu which can set the all of the functions.

5-4-1. Start "SET UP" Mode (Pass Word Not use)

SETUP

Press  key four times within 2sec
When "SET UP" is displayed, SETUP Mode is activated

5-4-2. Start "SET UP" Mode (Pass Word Use – Refer F-function 95)

P-W

Press  key four times within 2sec
If "P-W" displays, input 4 characters password.

SETUP

If Password is right, "SETUP" Mode starts.

Err

If Password is wrong, it is back to weighing display.

No password at factory default.




If you set password by "F95". "TEST" mode, you cannot start "SETUP" Mode without password. Please don't forget the pass word.

After starting "Calibration" mode, and "Test" mode, serial I/F will be closed.

■ Starting F-FUNCTION Mode

Press  key 4 times → Input Password → Displaying "SETUP" press  key.

F 0 1 - 0 0



"A" : Make the function number and press  key.

"B" : Whenever press  key the the function number will increase.

"C" : Make the set value and press  key and save.

■ F-Function List

General Function Setting ("●" Factory default set value)

Weighing Data Save Method selection			
F01	●	0	Non-Save Mode (Weight Data & weighing counter)
		1	Save Mode (Weight Data & weighing counter)
Weight –Back up selection			
F02		0	Normal Mode
	●	1	Weight Back up Mode
Motion Band Range setting			
F03	05	01 ┆ 99	This is set "Steady" acceptable range of weighing part. If there is vibration on weighing part, you can set this function and reduce the vibration effect on weighing process. 1 : Weak vibration ~ 99 : Strong Vibration
Zero Tracking Compensation Range setting			
F04	05	00 ┆ 99	Due to external causes (Temperature, wind, and dust), there will be small weight difference, the Indicator will ignore the weight difference and display as Zero.
Auto Zero Range setting			
F05	00	00 ┆ 99	Within the "Auto Zero" range, weighing part is steady, indicator will display current weight as "Zero" If the weighing part is not "Steady", indicator will display current weight. (Auto Zero Range : ± Set value + weight unit)
Digital Filter setting			
F06	04	00~40	0 (Weak vibration) ~ 40 (Strong Vibration)
Zero key Operation mode selection			
F07		0	Activate only under "Steady" condition
	●	1	Always activate
Zero key Operation Range selection : (-) value is same to (+)			
F08		0	Activated within 2% of Max. Capacity
		1	Activated within 5% of Max. Capacity
	●	2	Activated within 10% of Max. Capacity
		3	Activated within 20% of Max. Capacity
		4	Activated within 50% of Max. Capacity
		5	Activated within 100% of Max. Capacity
		6	There is no limit of Zero key operation range.
※ CAUTION : If setting over than 10%, The display weight could be over than Load cell input signal or Max. Capacity and it may display "CELL-Err" or incorrect weight value.			

Tare key Operation Range selection : (-) value is same to (+)			
F09		0	Activated within 10% of Max. Capacity
		1	Activated within 20% of Max. Capacity
	●	2	Activated within 50% of Max. Capacity
		3	Activated within 100% of Max. Capacity
"Hold" Mode selection			
F10	●	0	Peak Hold : Measure Max. weight value and hold on display.
		1	Sample Hold : Hold current weight until "Hold Reset"
		2	Average Hold : Hold average value (Refer F-F50)
"STEADY" condition check time setting			
F11	03	00 ┆ 09	During the set time period, estimate weighing part's "STEADY" condition and display. If you set small value, indicator will take "STEADY" fast, if you set value, indicator will take "STEADY" slow. (0.5sec per set value)
Display Up-Date speed setting			
F12	●	1	60/sec
		2	30/sec
		3	20/sec
		4	15/sec
		5	10/sec
		6	6/sec
		7	3/sec
		8	2/sec
		9	1/sec
Weight Display selection under "Unpass / OverLoad" condition			
F13		0	Not Display Weight (just "UNPASS" or "-OL-" is displayed)
	●	1	Display Weight (with a flash)
Equipment No. setting – ID No.setting			
F18	01	01~99	ID No. setting with No. key. (01~99 settable)

■ Communication Mode Setting

Parity Bit selection Mode					
F30	●	0	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Non)
		1	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)
		2	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)
		3	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)
		4	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Odd)

		5	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Even)
		6	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)
		7	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)
		8	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Odd)
		9	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Even)
Serial Communication Speed selection					
F31		0	2,400bps		
		1	4,800bps		
	●	2	9,600bps		
		3	14,400bps		
		4	19,200bps		
		5	28,800bps		
		6	38,400bps		
		7	57,600bps		
		8	76,800bps		
		9	115,200bps		
DATA Transference Method selection					
F32		0	Simplex Mode / Stream Mode		
	●	1	Duplex Mode / Command Mode		
		2	Print Mode		
"Check-Sum" detection selection (Under F32-01 setting, only)					
F34	●	0	Check-Sum Not Use		
		1	Check-Sum Use		
Under Stream Mode select the way transmit data protocol/frame (basic port)					
F35	●	0	Transmit by Protocol		
		1	Transmit by frame (in case of using specific utility)		
Caution : In case of "Transmit by frame" & under 14,400bps setting(F31), the speed of system will be slow.					
DATA Transference Mode selection (Under F32-00 setting, only)					
F36	●	0	Always		
		1	Single time data transference, Whenever the weight is steady over Empty range.		
		2	Single time data transference, at first steady point, over Empty range.		
		3	Data transference, Whenever "Print" key input		
DATA Transference Format selection (Under F32-00 setting, only)					
F37	●	0	Format 1 (recommended when use external display)		

		1	Format 2. (Format 1 + ID No.)
		2	Format 3. (recommended when connecting to PLC or PC)
		3	CAS Format
Print Mode selection (Under F32-02 setting, only)			
F38	<input checked="" type="radio"/>	0	Manual Print : Whenever "Print" key input.
	<input type="radio"/>	1	Auto print (at the first Steady point over "EMPTY" range or Whenever "Print" key input.)
	<input type="radio"/>	2	Auto print (Whenever Steady status at over "EMPTY" range or Whenever "Print" key input.)

■ Print Mode Setting

Weight Unit selection			
F41	<input checked="" type="radio"/>	0	Kg
	<input type="radio"/>	1	g
	<input type="radio"/>	2	t
Print Format selection			
F42	<input checked="" type="radio"/>	0	Continuous Print - Serial No. and Weight will be printed continuously.
	<input type="radio"/>	1	Single Print - Date, Time, S/N, ID No. Weighing Data will be print
SUB/GRAND Total Data Delete selection			
F44	<input checked="" type="radio"/>	0	Not deleted (= manual Delete mode)
	<input type="radio"/>	1	Automatically Deleted.-After print out SBU/GRAND Total.
Paper Withdraw Rate setting (After SUB/GRAND Total Print)			
F45	03	00~09	Whenever set value increased as 1, then 1 line will be added.
Paper Withdraw Rate setting (After Continuous/Single Print)			
F46	03	00~09	Whenever set value increased as 1, then will be added.
Printing Language Selection			
F47	<input checked="" type="radio"/>	0	KOREAN
	<input type="radio"/>	1	ENGLISH
Minus(-) symbol Print selection			
F49	<input checked="" type="radio"/>	0	Print minus(-) symbol, if the weight is minus(-).
	<input type="radio"/>	1	Ignore minus(-) symbol
Set time of "Average Hold"			
F50	03	00~9	When setting "Average Hold", set the time. (unit : sec) ※Automatic Hold Rest , After set time.

■ Other Setting Mode

EMPTY Range setting	
F80	<p>10</p> <p>You can set "EMPTY" Range. Ex) "0" setting : When Net Zero, "Zero" status lamp is ON. "200" setting : Under "200", "Zero" Status lamp is ON.</p>
TIME(H,M,S) Check / Change (every 24Hours)	
F90	<p>Check Current DATE data or you can Change to new date</p>
TIME Check / Change	
F91	<p>Check Current TIME data or you can Change to new time</p>
SETUP Mode Password Key Setting / Change	
F95	<p>Setting the password</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">1- - - -</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">2- - - -</div> </div> <p>1) When "1" shows input the password with 4 characters.</p> <p>2) When "2" displays input the same password again.</p>
	<p>Change the password</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">P-UU</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">1- - - -</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">2- - - -</div> </div> <p>1) If "P-W" displays input current password</p> <p>2) If "1" displays input the new password .</p> <p>3) If "2" displays input the new password again.</p>
	<p>Deactivate Lock setting</p> <p>If you set the password including  key , it is unlocked. When setting password you cannot start "SETUP" mode without password, do not forget your password.</p>
Program & Hard ware Version Check	
F98	<p>Check the Program & Hard ware version Ex) "100 1.04" means H/W : ver.1.00 & S/W : ver.1.04</p>

5-5. Test Mode

Before starting the TEST mode, please remove operating devices.

SETUP

TEST

Press  key 4 times then "SETUP" displays input  key to start TEST mode.

TEST MODE 1			
			
ESC / BACK	Analog value Check Mode	Serial port test mode	Key/Digital Input Check Mode

5-5-1. Analog Check Mode

Under this mode, you can check analogue value to real digital value through Display. The last digital value can be fluctuated

 key 4 times →  key →  key

2 10375

If there is no change although pressing keys or loading some force on/in weighing part, it may something wrong with load cell, cable, connector or A/D board. (-1048575~1048575)

2 10375

12 1037

12 103



: Displaying 1~100,000




: Displaying 10~1,000,000



: Displaying 100~10,000,000

5-5-2. Key / Digital input Test Mode

Under this mode, you can test Key input and Digital Key input test



5-5-3. Serial Interface Test Mode.

This is the mode to check RS232C port.




RS-232C RxD TxD GND	Short between Rxd & Txd of Indicator terminal.
COM1	Enter the RS232C test mode and "COM1" is displaying, then press key
PASS	Displaying "PASS" is that the port works well.
UNPASS	Displaying "UNPASS" means that the port 's IC chip has a problem. Contact your seller or the main office..

※ If you send "Testing protocol" from PC to Indicator, at the normal operation Display will blink.


6. INTERFACE

6-1. Serial Interface

6-1-1. Serial Interface (RS-232C)




6-1-2. Current Loop



Serial communication interface is sensitive to electric noise.
 Install isolated place from Power cable or other electric cables and wires, and please use shielded cable for better performance.


6-1-4. Data Format

1. Data Format1 : ID Number is not be transferred.(Refer "FUNCTION 37/F67-00" setting)




Header1	Header2
OL : OVER LOAD	NT : NET-WEIGHT(Tare is not set)
ST : STEADY	GS : when setting TARE
US : UNSTEADY	

2. Data Format2 : ID Number + Data Transference (Refer F-function 37-01, F18)




Header1	Header2
OL : OVER LOAD	NT : NET-WEIGHT(Tare is not set)
ST : STEADY	GS : when setting TARE
US : UNSTEADY	

3. Data Format3 : ID Number + State (F37-03 setting)



Header1	Header2
O : OVER	G : Gross weight
S : STEADY	N : Net weight
U : UNSTABLE	

4. CAS Format (22byte)




LAMP DISPLAY

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	0	1	1	1	1	1	1
1	STEADY	1	Hold	Print	Gross Weight	TARE	ZERO

Header1	Header2
OL : OVER LOAD	NT : GROSS weight
ST : STEADY	GS : Net weight
US : UNSTEADY	

6-1-5. Command Mode (F32-01 setting)

Under "Command Mode", Indicator will recognize the receipt of Order based on 02h(Header) and 03h(END) signal, and transfers ACK/ NAK).



※Although wrong value is transmitted, the communication format is matched, then ACK is transmitted.

Read Command

1.Current Weight data																																																																																								
ASCII : STX ID(2Byte) RCWT ETX	HEX : 02 30 31 52 43 57 54 03																																																																																							
SI 300 response	STX ID RCWT State1(1byte) State2(1byte) P decimal point(1byte) +/- (1byte) Current weight(7byte) unit(2byte) ETX																																																																																							
	State1 : O(Over load) , S(Steady), U(Unsteady) State2 : N(Net weight), G(Gross weight), P+No. : decimal point number																																																																																							
Ex) Steady(S), TARE not used(N), 0.000kg <u>State1, State2, Decimal point</u>																																																																																								
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>C</td><td>W</td><td>T</td><td>S</td><td>N</td><td>P</td><td>3</td><td>+</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>k</td><td>g</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>43h</td><td>57h</td><td>54h</td><td>53h</td><td>4Eh</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>6Bh</td><td>67h</td><td>03h</td> </tr> </table>		STX	ID	R	C	W	T	S	N	P	3	+	0	k	g	ETX	02h	30h	31h	52h	43h	57h	54h	53h	4Eh	50h	33h	2Bh	30h	30h	6Bh	67h	03h																																																							
STX	ID	R	C	W	T	S	N	P	3	+	0	k	g	ETX																																																																										
02h	30h	31h	52h	43h	57h	54h	53h	4Eh	50h	33h	2Bh	30h	6Bh	67h	03h																																																																									
2. Indicator memory data																																																																																								
ASCII : STX ID(2Byte) RCWD ETX	HEX : 02 30 31 52 43 57 44 03																																																																																							
SI 300 response	STX ID RCWD P decimal point(1byte)DATE(6byte) TIME(6byte) the no. of weighing (6byte) +/- TARE(7Byte) +/- current weight(7byte) unit(2byte) ETX																																																																																							
	Ex) DATE : Aug 12 th ,2009, TIME : 12:00:00, the no. of weighing : 10, TARE : 2.000kg, current weight : 3.000kg <u>decimal point</u>																																																																																							
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>C</td><td>W</td><td>D</td><td>P</td><td>3</td><td>0</td><td>9</td><td>0</td><td>8</td><td>1</td><td>2</td><td>1</td><td>2</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>43h</td><td>57h</td><td>44h</td><td>50h</td><td>33h</td><td>30h</td><td>39h</td><td>30h</td><td>38h</td><td>31h</td><td>32h</td><td>31h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td> </tr> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>+</td><td>0</td><td>0</td><td>0</td><td>2</td><td>0</td><td>0</td><td>0</td><td>+</td><td>0</td><td>0</td><td>0</td><td>3</td><td>0</td><td>0</td><td>0</td><td>ETX</td> </tr> <tr> <td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>2Bh</td><td>32h</td><td>30h</td><td>30h</td><td>33h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		STX	ID	R	C	W	D	P	3	0	9	0	8	1	2	1	2	0	0	0	0	02h	30h	31h	52h	43h	57h	44h	50h	33h	30h	39h	30h	38h	31h	32h	31h	31h	30h	30h	30h	30h	0	0	0	0	1	0	+	0	0	0	2	0	0	0	+	0	0	0	3	0	0	0	ETX	30h	30h	30h	30h	31h	30h	2Bh	30h	30h	30h	32h	30h	30h	30h	2Bh	32h	30h	30h	33h	30h	30h	30h	03h
STX	ID	R	C	W	D	P	3	0	9	0	8	1	2	1	2	0	0	0	0																																																																					
02h	30h	31h	52h	43h	57h	44h	50h	33h	30h	39h	30h	38h	31h	32h	31h	31h	30h	30h	30h	30h																																																																				
0	0	0	0	1	0	+	0	0	0	2	0	0	0	+	0	0	0	3	0	0	0	ETX																																																																		
30h	30h	30h	30h	31h	30h	2Bh	30h	30h	30h	32h	30h	30h	30h	2Bh	32h	30h	30h	33h	30h	30h	30h	03h																																																																		
3. Grand Total data																																																																																								
ASCII : STX ID(2Byte) RGRD ETX	HEX : 02 30 31 52 43 57 44 03																																																																																							
SI 300 response	STX ID RGRD P decimal point(1byte) the no. of weighing (6byte) Accumulated weight(10byte) unit(2byte) ETX																																																																																							
	Ex) the no. of weighing : 10 , Accumulated Weight : 10.000kg <u>decimal point</u>																																																																																							
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>G</td><td>R</td><td>D</td><td>P</td><td>3</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>47h</td><td>52h</td><td>44h</td><td>50h</td><td>33h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		STX	ID	R	G	R	D	P	3	0	0	0	0	1	0	0	0	0	0	1	0	0	0	0	ETX	02h	30h	31h	52h	47h	52h	44h	50h	33h	30h	30h	30h	30h	31h	30h	30h	30h	30h	30h	31h	30h	30h	30h	03h																																							
STX	ID	R	G	R	D	P	3	0	0	0	0	1	0	0	0	0	0	1	0	0	0	0	ETX																																																																	
02h	30h	31h	52h	47h	52h	44h	50h	33h	30h	30h	30h	30h	31h	30h	30h	30h	30h	30h	31h	30h	30h	30h	03h																																																																	

4.Finished Weight data																																				
ASCII : STX ID(2Byte) RFIN ETX	HEX: 02 30 31 52 46 49 4E 03																																			
SI 300 response	STX ID RFIN P decimal point(1byte) +/- Finished weight(7byte) ETX																																			
Ex) Finished weight : 2.000kg decimal point																																				
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>F</td><td>I</td><td>N</td><td>P</td><td>3</td><td>+</td><td>0</td><td>0</td><td>0</td><td>2</td><td>0</td><td>0</td><td>0</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>46h</td><td>49h</td><td>4Eh</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		STX	ID	R	F	I	N	P	3	+	0	0	0	2	0	0	0	ETX	02h	30h	31h	52h	46h	49h	4Eh	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h
STX	ID	R	F	I	N	P	3	+	0	0	0	2	0	0	0	ETX																				
02h	30h	31h	52h	46h	49h	4Eh	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h																			
5. Current time Data																																				
ASCII : STX ID(2Byte) RTIM ETX	HEX: 02 30 31 52 54 49 4D 03																																			
SI 300 response	STX ID RTIM Current Time(6byte) ETX																																			
Ex) Time : 12:00:00																																				
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>T</td><td>I</td><td>M</td><td>1</td><td>2</td><td>0</td><td>0</td><td>0</td><td>0</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>54h</td><td>49h</td><td>4Dh</td><td>31h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		STX	ID	R	T	I	M	1	2	0	0	0	0	ETX	02h	30h	31h	52h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h								
STX	ID	R	T	I	M	1	2	0	0	0	0	ETX																								
02h	30h	31h	52h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h																							
6. Current date Data																																				
ASCII : STX ID(2Byte) RDAT ETX	HEX : 02 30 31 52 44 41 54 03																																			
SI 300 response	STX ID RDAT Current Date(6byte) ETX																																			
Ex) Date : Aug 12 th ,2009																																				
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>D</td><td>A</td><td>T</td><td>0</td><td>9</td><td>0</td><td>8</td><td>1</td><td>2</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>41h</td><td>41h</td><td>54h</td><td>30h</td><td>39h</td><td>30h</td><td>38h</td><td>31h</td><td>32h</td><td>03h</td> </tr> </table>		STX	ID	R	D	A	T	0	9	0	8	1	2	ETX	02h	30h	31h	52h	41h	41h	54h	30h	39h	30h	38h	31h	32h	03h								
STX	ID	R	D	A	T	0	9	0	8	1	2	ETX																								
02h	30h	31h	52h	41h	41h	54h	30h	39h	30h	38h	31h	32h	03h																							
7. Tare data																																				
ASCII : STX ID(2Byte) RTAR ETX	HEX : 02 30 31 52 54 41 52 03																																			
SI 300 response	STX ID RTAR P decimal point(1byte) +/- (1byte) TARE value(7byte) ETX																																			
Ex) TARE : 2.000kg decimal point																																				
<table border="0"> <tr> <td>STX</td><td>ID</td><td>R</td><td>T</td><td>A</td><td>R</td><td>P</td><td>3</td><td>+</td><td>0</td><td>0</td><td>0</td><td>2</td><td>0</td><td>0</td><td>0</td><td>ETX</td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>54h</td><td>41h</td><td>52h</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		STX	ID	R	T	A	R	P	3	+	0	0	0	2	0	0	0	ETX	02h	30h	31h	52h	54h	41h	52h	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h
STX	ID	R	T	A	R	P	3	+	0	0	0	2	0	0	0	ETX																				
02h	30h	31h	52h	54h	41h	52h	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h																			



Recommended Interval of READ COMMAND is min.60ms, 70ms is recommended, under 9600bps setting.

Min.60ms is required between each Read Command(under RCWD)

Min. interval is changed when data's length & speed are changed.

Min Interval : 20ms under 2400bps(RCWD)

Min Interval : 40ms under 115200bps (RCWD)

■Write Command

Zero (same as "ZERO" key)																												
ASCII : STX ID(2Byte) WZER ETX	HEX: 02 30 31 57 5A 45 52 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
TARE																												
ASCII : STX ID(2Byte) WTAR ETX	HEX: 02 30 31 57 54 41 52 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
TARE reset																												
ASCII : STX ID(2Byte) WTRS ETX	HEX: 02 30 31 57 54 52 53 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
HOLD																												
ASCII : STX ID(2Byte) WHOL ETX	HEX: 02 30 31 57 48 4F 4C 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
HOLD reset																												
ASCII : STX ID(2Byte) WHRS ETX	HEX: 02 30 31 57 48 52 53 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
PRINT																												
When transfer format, "F46 : plus line" and "F34 : checksums are not applied.																												
ASCII : STX ID(2Byte) WPRT ETX	HEX: 02 30 31 57 50 52 54 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
PRINT grand total																												
ASCII : STX ID(2Byte) WGPR ETX	HEX: 02 30 31 57 47 50 52 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
Delete grand total																												
ASCII : STX ID(2Byte) WGTC ETX	HEX: 02 30 31 57 47 54 43 03																											
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											
Date setting																												
ASCII : STX ID(2Byte) WDAT current DATE (6byte) ETX																												
Ex) Date : Aug 12 th ,2009																												
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>STX</th> <th>ID</th> <th>W</th> <th>D</th> <th>A</th> <th>T</th> <th>0</th> <th>9</th> <th>0</th> <th>8</th> <th>1</th> <th>2</th> <th>ETX</th> </tr> </thead> <tbody> <tr> <td>02h</td> <td>30h</td> <td>31h</td> <td>57h</td> <td>44h</td> <td>41h</td> <td>54h</td> <td>30h</td> <td>39h</td> <td>30h</td> <td>38h</td> <td>31h</td> <td>32h</td> <td>03h</td> </tr> </tbody> </table>		STX	ID	W	D	A	T	0	9	0	8	1	2	ETX	02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h
STX	ID	W	D	A	T	0	9	0	8	1	2	ETX																
02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h															
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																											

Time setting																													
ASCII : STX ID(2Byte) WTIM Time (6byte)ETX																													
Ex) Time : 12:00:00																													
<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;">STX</td> <td style="padding: 0 5px;">ID</td> <td style="padding: 0 5px;">W</td> <td style="padding: 0 5px;">T</td> <td style="padding: 0 5px;">I</td> <td style="padding: 0 5px;">M</td> <td style="padding: 0 5px;">1</td> <td style="padding: 0 5px;">2</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">ETX</td> </tr> <tr> <td style="padding: 0 5px; text-align: center;">02h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">31h</td> <td style="padding: 0 5px; text-align: center;">57h</td> <td style="padding: 0 5px; text-align: center;">54h</td> <td style="padding: 0 5px; text-align: center;">49h</td> <td style="padding: 0 5px; text-align: center;">4Dh</td> <td style="padding: 0 5px; text-align: center;">31h</td> <td style="padding: 0 5px; text-align: center;">32h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">03h</td> </tr> </table>		STX	ID	W	T	I	M	1	2	0	0	0	0	ETX	02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h	
STX	ID	W	T	I	M	1	2	0	0	0	0	ETX																	
02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h																
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																												
Change S/N																													
ASCII : STX ID(2Byte) WSNO S/N(6byte)ETX																													
Ex) S/N is changed to 100																													
<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;">STX</td> <td style="padding: 0 5px;">ID</td> <td style="padding: 0 5px;">W</td> <td style="padding: 0 5px;">S</td> <td style="padding: 0 5px;">N</td> <td style="padding: 0 5px;">O</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">1</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">0</td> <td style="padding: 0 5px;">ETX</td> </tr> <tr> <td style="padding: 0 5px; text-align: center;">02h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">31h</td> <td style="padding: 0 5px; text-align: center;">57h</td> <td style="padding: 0 5px; text-align: center;">53h</td> <td style="padding: 0 5px; text-align: center;">4Eh</td> <td style="padding: 0 5px; text-align: center;">4Fh</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">31h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">30h</td> <td style="padding: 0 5px; text-align: center;">03h</td> </tr> </table>		STX	ID	W	S	N	O	0	0	0	0	1	0	0	ETX	02h	30h	31h	57h	53h	4Eh	4Fh	30h	30h	30h	31h	30h	30h	03h
STX	ID	W	S	N	O	0	0	0	0	1	0	0	ETX																
02h	30h	31h	57h	53h	4Eh	4Fh	30h	30h	30h	31h	30h	30h	03h																
SI 300 response	normal: STX ID ACK ETX error: STX ID NAK ETX																												



Recommended Comm. Interval of WRITE COMMAND is Min. 100ms.

Comm. Interval of WPRT is Min.300ms

You have to guarantee Min. 100ms interval between two different commands.



Response for WPRT will be output through Print Port, set by F32-0.

■ Command Mode Example


READ COMMAND

Ex.) Current Weight Command(RCWT), ID No. : 01, Current Weight : 7,000kg

1) P.C Read Command Format (STX ID NO. RCWT ETX) "Check-sum" not used.



2) When PC requests to Indicator, Format(STX ID RCWT ETX) CHCEK SUM is used.




WRITE COMMAND


Ex) SP1 Setting Command, ID No : 01, New SP1 Set value : 0.600kg

1) PC Write command format (STX ID WPR1 000.600 ETX) "CHECK SUM" not use.

PC transmits to SI300



SI300 Response to PC




Normal operation



Incorrect operation

1) PC Write command format (STX ID WPR1 000.600 ETX) "CHECK SUM" use.

PC transmits to SI300



SI300 Response to PC



Normal operation



Incorrect operation

All Read/Write command must be use "HEX CODE"..

How to Calculate Check sum.

- Sum the value from "STX" to "ETX" and converts to ASCII(2byte) and transfer.

Convert the Sum value(HEX) to ASCII and transmit(28byte) .

ex) The sum HEX value from STX to ETX(02,30,31,52,43,57,54,03) is 1A6h.

Then, divide 1A6h by 100h(1A6h/100h). the rest of result is A6h.

Calculated remainder value is A6h, then convert A6h to ASCII, 41(A), 36(6), and transfer.

6-2 Serial Print (F32-02 setting) – RS-232 Serial Interface.

It can be connected with all kinds of Serial interface printer, but the printing format is already programmed and fixed with SE7200/7300 model.

6-2-1. Printing Format

Using the RS-485 or 422 interface, please use convertor and converts to RS-232 and connect with Serial printer.

If you use RS-232 serial interface, connect directly without any convertor.

English Format (F47-01)

```

=====
DATE :      2009-05-10
TIME :      18:00:10
COUNT      WEIGHT
   1        + 1.330kg
   2        + 5.350kg
   3        + 1.380kg
   4        + 2.330kg
  
```

Continuous Print Format(F42-00)

```

=====
DATE :      2009-05-10
TIME :      18:00:10
COUNT      WEIGHT
   2        + 5.350kg

=====
DATE :      2009-05-10
TIME :      18:00:10
COUNT      WEIGHT
   3        + 1.280kg
  
```

Single Print Format(F42-01)

```

=====
                    TOTAL
DATE :      2009-05-10
TIME :      18:00:10
COUNT :      10
TOTAL WEIGHT : 258.145kg
=====
                    TOTAL DELETE
=====
  
```

Grand Total Print

(Grand Total Print delete setting, F44-01)

※ Under "F01-01" setting, the current weight is saved and print out.

7. Error & Treatment

7-1. Load Cell Installation

Error	Cause	Treatment	Remarks
Weight Value is unstable	1) Load cell broken 2) Load cell isolation resistance error 3) Weighing part touches other devices or some weight is on the weighing part 4) Summing Board Error	1) Measure input/output resistance of Load cell. 2) Measure Load cell isolation resistance	1. Input Resistance of "EXC+" and "EXC-" is about $400\Omega \pm 30$ 2. Output Resistance of "SIG+" and "SIG-" is about $350\Omega \pm 3.5$ 3. Isolate Resistance is more than $100M\Omega$
Weight Value is increased regular rate, but not return to "Zero"	1) Load cell Error 2) Load cell connection Error	1) Check Load cell connection 2) Measure Load cell Resistance	
Weight Value is increased to under Zero	Load cell Output wire (SIG+, SIG-) is switched	Make wire correction	
"UN PASS" display	Load cell broken or Indicator connection Error	Load cell Check Load cell connection Check	
	Power was "ON" when some weight is on the load cell.	Remove weight on the Load cell	
"OL" or "UL" display(Over Load)	1) Load cell broken or Indicator connection Error 2) Loading over than Max. Capacity	1) Load cell Check 2) Load cell connection Check 3) Remove over loaded weight	

7-2. Calibration Process

Display	Cause	Treatment
<i>Err01</i>	When Max.capacity/digit value is over 20,000	Re-input the Max. Capacity, less than 20.00 (Max. Capacity / Digit)
<i>Err04</i>	Standard weight value is over than Max. Capacity	Re-input Standard weight value with Number keys, under Max. Capacity
<i>Err05</i>	Standard weight value is less than 10% of Max. Capacity	Re-input Standard weight value with Number keys, more than 10% of Max. Capacity
<i>Err06</i>	<ol style="list-style-type: none"> 1. Amp. Gain is too big 2. Sig+ and Sig- wire connection error 3. Test weight is not loaded 	<p>Check standard weight's weight with set value.</p> <p>If there is difference between set value and real weight, please re-input the value (set value is too small)</p>
<i>Err07</i>	<ol style="list-style-type: none"> 1. Amp. Gain is too small 2. Sig+ and Sig- wire connection error 3. Test weight is not loaded 	<p>Check standard weight's weight with set value.</p> <p>If there is difference between set value and real weight, please re-input the value (set value is too big)</p>
<i>Err08</i>	Under "F-function" model, set value is "N.A"	Check the correct value and re-input
<i>Err-A</i>	When there is continuous vibration on the weighing part,, indicator cannot process calibration any more.	<ul style="list-style-type: none"> - Find vibration cause and remove - Load cell check - Load cell cable and connecting condition check

7-3. Digital Weighing Indicator

Display	Cause	Treatment
<p>"CELL- Er"</p> <p>or</p> <p>"OVER"</p>	<p>1. Load cell Error</p> <p>2. Load cell cable Error</p> <p>3. Load cell connection Error</p> <p>4. A/D Board Error</p> <p>5. If Analogue value is over 1,040,000.</p> <p>※ When weigh "-" value, If it is over set max capa, "OVER" is displayed.</p> <p>Ex) Even though set max capa is "100" and it is over "-100", "OVER" is displayed.</p>	<p>1. Under "TEST" mode 1, check analogue value. If you cannot get any analogue value or there is no change although adding load, please check load cell, load cell cable, connection conditions first.</p> <p>2. Replace another load cell, and check the indicator condition. If you have same problem, please replace new indicator and check A/D board error.</p> <p>3. Try to connect the indicator's A/D with the other indicator.</p> <p>4. Check the power and connection of terminal.</p>
"UNPASS"	<p>1. Power is ON, when some materials are on weighing part.</p> <p>※ Under "Normal Mode", if there are more than 20% loading of Max. capacity, "Un-Pass" display will be appeared and indicator will stay until removing the load.</p> <p>※ Setting Back-up mode it can memory empty value, and it becomes set value without displaying "Un-pass")</p>	<p>1. If you set "Normal Mode", please check weighing part empty or not before turn on the power. If there are some materials in/on weighing part, please remove those materials and turn on the power.</p> <p>2. Please try to set F02-01(Back-up) mode so that the indicator can remember first empty value.</p>
"SET"	<p>When Power is on, "SET" displays. It means EEPROM has some problem.</p>	Please contact the distributor or Head Office.
"HALT"	H/W has some problem.	
"E-Err"	The dead Battery	

※ Under "CELL-Err", Zero key, Tare key, Hold key and print key will not be activated.

WARRANTEE CERTIFICATION		
<p>This product is passed "Sewhacnm's strict quality test.</p> <p>If there is defect of manufacturing or abnormal detection within warrantee period, please contact our Agent or Distributor with this Warrantee certificate.</p> <p>Then, we will repair or replace free of charge.</p>		
WARRANTEE CLAUSE		
<p>1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date</p> <p>2. Warrantee Exception Clause</p> <ul style="list-style-type: none"> - Warrantee period is expired. - Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm's permission. - Any kinds of Mal-function, Defection, or External damage, caused by operator - Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent. - Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this manual. - Any kinds of Mal-function, Defection caused by "Force Majeur", like Fire, Flood. - Without presentation of this "Warrantee Certification". <p>3. Other</p> <ul style="list-style-type: none"> - Any kinds of "Warrantee Certification" without authorized Stamp is out of validity 		
<p>SEWHACNM Co.,Ltd. #504-302, 397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea</p> <p>Made in KOREA</p> <p>Website : http://www.sewhacnm.co.kr , Email : sales@sewhacnm.co.kr</p>	Product	Digital Weighing Indicator
	Model	SI 300
	Serial No.	
	AUTHORIZED STAMP	