

Digital Weighing Controller SI 4010

Instruction Manual





CONTENTS

1. Before Installation	 3 page
2. Introduction	 4 page
3. Specification	 5 page
4. Installation	 11 page
4-1. External Dimension & Cutting Size	 11 page
4-2. Installation Components	 12 page
4-3. Load Cell Installation	 12 page
5. Set-up	 13page
5-1. Calibration	 13 page
5-2. TEST Weight Calibration Mode	 13 page
5-3. Simulation Calibration Mode(Without Test Weight)	 16 page
5-4. Set-up	 19 page
5-5. F-Function	 20 page
6. Interface	 27 page
6-1. Serial Interface (RS-232C)	 27 page
6-2. Current Loop Interface	 31 page
6-3. Analog Output Interface (0~10V)	 32 page
6-4. Analog Output Interface (4~20mA)	 33 page
6-5. Serial Interface (RS-232C / 422 / 485)	 34 page
6-6. BCD Input (BCD INPUT: P/N Change)	 35 page
6-7. BCD Output	 36 page
6-8. Print Interface	 37 page
6-9. Command Mode	 38 page
7. Error & Treatment	 40 page
7-1. Load Cell Installation	 40 page
7-2. Calibration Process	 40 page
7-3. Indicator Error & Treatment	 41 page
7-4. Indicator Test Mode	 42 page
Warrantee Certification	 43 page

1. BEFORE INSTALLATION

1-1. Caution / Warning Marks

. warning	This mark warns the possibility to arrive death or serious injury in case of wrongly used.
Zeaution !	This mark cautions the possibility to arrive serious human body injury or product lose in case of wrongly used.

1-2. Other Marks

	Warning for Electric Shock or Damage. Please do not touch by hand	
(±)	Protective Ground(Earth) terminal	
	Prohibition of Operation process	

1-3. Copy Rights

- 1). All Right and Authority for this Manual is belonged to Sewhacnm Co.,Ltd.
- 2). Any kinds of copy or distribution without Sewhacnm Co.,Ltd's permission will be prohibited.

1-4. Inquiries

If you have any kinds of inquiries for this model, please contact with your local agent or Head Office.

Head Office : Sewhacnm Co.,Ltd.

Website : www.sewhacnm.co.kr
Email : sales@sewhacnm.co.kr

2. INTRODUCTION

2-1. Introduction

Thank you for your choice, this "SI 4010" Industrial Digital Weighing Indictor..

This "SI 4010" model is simple weight display purpose with Large display(1inch), and powerful communication performance.

With 2ports serial port communication and High Speed A/D conversion performance will lead you to precise weighing process.

Please review this instruction Manual and learn more about information about "SI 4000".

Enjoy your process efficiency with "SI 4010" Weighing Indicator..

2-2. Cautions



- 1) Don't drop on the ground or avoid serious external damage on item.
- 2) Don't install under sunshine or heavy vibrated condition.
- 3) Don't install place where high voltage or heavy electric noise condition.
- 4) When you connect with other devices, please turn off the power of item.
- 5) Avoid from water damage.
- 6) For the improvement of function or performance, we can change item specification without prior notice or permission.
- 7) Item's performance will be up-dated continuously base on previous version's performance.

2-3. Features

- 1) All Modules and Option Cards are isolated to maximize accuracy and performance.
- 2) External input terminal inside.(4pcs:Can be set by F11 mode)
- 3) By using "Photo-Coupler" on each module (Option, Analog board, In/Out), we improved "Impedance problem", "Isolation ability among inputs", "Leading power problem", and "Noise covering function".
- 4) Data back-up function, when the sudden power off.
- 5) Polycarbonate film panel, strong against dust and water.
- 6) 2port Serial Interface RS-232C (Com. Port1) is standard installed.
- 7) HIGH / LOW Set points and Free Fall function for HIGH Set point.
- 8) Weight Unit selection Function added. ("g", "kg", "t" selectable F40)
- 9) Variable options(Order in advance, Refer Chapter 5. Interface)

3. SPECIFICATION

3-1. Analog Input & A/D Conversion

Input Sensitivity	0.2₺V / Digit	
Load Cell Excitation	DC 10V (- 5V ~ + 5V)	
Max Input Signal	Max3.2mV/V	
Tomposeture Coefficient	[Zero] ±20PPM/℃	
Temperature Coefficient	[Span] ±20PPM/℃	
Input Noise	±0.3 / P.P	
Input Impedance	Over 10™	
A/D Conversion Method	Sigma-Delta	
A/D Resolution(Internal)	520,000 Count(19bit)	
A/D Sampling Rate	Max 500times / Sec	
Non-Linearity	0.005% FS	
Display Resolution(External)	1/20,000	

3-2. Digital Part

Display	Parts Specification	
	Main Display	7Segments, RED FND Display
		Size :24.5mm(H) Large Display (1inch)
Display	Min. Division	$\times 1, \times 2, \times 5, \times 10, \times 20, \times 50$
	Max display value	+999,950
	Under Zero value	"-" (Minus display)
Status lamp	Steady, Zero, Tare	C LED Division (00)
	kg, g, ton	Green LED Display(20)
Кеу	Number Key : 10 ea , Function : 3 ea , CAL. Lock key : 1 ea	

3-3. General Specification

Power Supply	AC110/220V±10%), 50/60Hz, about 30VA	
Operating Temperature Range	-10℃ ~ 40℃	
Operating Humidity Range	Under 85% Rh (non-condensing)	
External Dimension	200mm(W) × 105mm(H) × 165mm(L)	
Net Weight(kg)	About 2.3kg	
Gross Weight(kg)	About 3.0kg	

^{*} AC 110V, Power supply is an optional before ex-factory.


3-4. Option Card

Option No.1	Printer Interface : Centronics Parallel	
Option No.2	Analog Output (0~10V or 0~5V)	
Option No.3	Analog Output (4~20mA)	
Option No.4	Serial Interface : RS-232C / 422 / 485	
Option No.5	BCD Input : Part No. Change Purpose	
Option No.6	BCD Output	
Option No.7	Ethernet	

^{*} Serial Interface (RS-232C) or Current Loop is Standard installed.

In the Optional Serial port, there is no Current Loop function.

3-5. Front Panel (Display / Key Pad)




Calibration Lock Key

3-5-1. Status Lamp (ANNUNCIATORS): "LED" Lamp is "ON"

Steady	When the weight is Steady, "LED" Lamp is "ON"		
Zero	When the current weight is Zero, "LED" Lamp is "ON"		
Torro	Tare function is set, "LED" Lamp is "ON"		
Tare	(Tare Reset → "LED" Lamp is "OFF".)		

3-5-2. Key Operation

	Make Weight value as Zero.		
	Under F08, you can set the Zero key operation range, as 2%, or 5%, or 10%, or 20% of		
ZERO	Max Capacity.		
	* Under "Tare" key input, Zero key will not be activate within operation range.		
	Make Weight value as Zero, including Tare Weight.		
(TADE	Under F09, you can set the Tare key operation range, as 10%, 20%, 50%, or 100% of Max Capacity.		
TAINL	Whenever pressing "Tare" key, you can set the Tare continuously.		
3	TARE RESET		
TARE	1. Remove the Set TARE function.		
KESET	- If you press this key, TARE set value will be removed and display gross weight.		
	Hold the Weight display when indicator detects "Peak Hold", or "Sample Hold".		
4	** You can select "Hold" function on F10.		
RESET	First input : HOLD is set Second input : HOLD Reset		
5	Under "TARE" setting, you can select weight display mode.		
NET/	First input, Gross Weight will be displayed, second input, Net weight will be displayed.		
GROSS	* This key will be activated only under "TARE" set.		
	You can set each weighing process as a certain P/N.		
6	And you can call certain P/N with pressing this key.		
P/N	P/N save : Select P/N and Enter key input.		
	P/N call : P/N + Number key + Enter		
	Print out All Part Nos' weighing data will be printed.		
GRAND	(Grand Total Data Print Out)		
8	Current Part No.'s weighing data will be printed.		
(CLIP	(Sub Total Data Print Out)		
SUB	(out Islan Islan Gul)		
L			



** Function Keys (Combined Key functions)

CLEAR	7 GRAND	Delete "Gross-Total data"
CLEAR	8 SUB	Delete "Sub-Total data"

3-6. Rear Panel





① POWER AC IN

- Power switch : Power on/off switch.

- Fuse : AC250V / 0.5A , $\phi 5.25$, 20mm.

- AC IN: Available Input AC 110V / 220V.



- ** The standard power supply is AC 220V(Fixed when ex-warehouse), if you want to have AC 110V, please inform in advance.
- ② Option Card 1
- 3 Option Card 2

*Option Card Connector installed for Optional Interface or Output.

(Printer I/F, Analog out, RS-422/485, or RS-232C(two port)

- **4** LOAD CELL Connector (N16-05)
- ⑤ SERIAL I/F


"RS-232C" or "CURRENT LOOP" (9Pin, D-Type Female) are built-in as standard

⑥ External Input: External control input for wired remote control.

Refer to F-Function F11 to select desired function mode.

4. INSTALLATION

4-1. External Dimension & Cutting Size




4-2. Installation Components

Power Cable	Communication Connector (D-SUB 9P)	Load-cell Cable

4-3. Load Cell Installation

4-3-1. Load Cell Connector Specification



4-3-2. Load Cell Installation

- 1) You can connect Max 8pcs of same capacity Load cells at once. (350 Ω)
- 2) You have to make horizontal balance on the ground.
- 3) If you install more than 2pcs of Load cells, use Summing box and adjust output signal difference as minimum. It can make wrong weighing process caused by each load cell's variation.
- 4) If there is some temperature difference around Load cell, it can cause wrong weight measurement.
- 5) Don't do Welding job or Arc discharge around installation place. But, there is no choice, please disconnect power cable and Load cell cable.
- 6) If you measure static electricity material, please make earth between down part and up part of Load cell.

4-3-3. Formula to plan the precise weighing system



This "SI 4010" weighing controller's Max input sensitivity is 0.2 // Digit.

And for precise weighing system, the following formula must be satisfied.

Caution: "Input sensitivity" means Min. output voltage variation of weighing part to change 1digit. So, please do not make large input voltage to make reliable weighing system.

	0.0.1/	$\mathbf{E} \times \mathbf{B} \times \mathbf{D}$	A: Load cell capacity(kg)
Single Load cell use	0.2μ V \leq	A	B : Load cell Voltage(mV)
			D : Digit
DI1 I111.	0.2μ V \leq	ExBxD	E : affirmation Voltage of Load cell
Plural Load cells use		$A \times N$	N : Number of Load cell

Example1)

Number of Load cell: 1pcs Load cell capacity: 500kg

 $Load\ cell\ Voltage: 2mV/V$

Digit: 0.05kg

Affirmation Voltage of Load cell: 5V

Max Capacity of Weighing System: 300kg

Then, estimation result for this weighing system with formula,

$$\frac{5000 \times 2 \times 0.05}{500} = 1 \ge 0.2 \,\mu\text{V}$$

The calculated value is larger than 0.2μ V, so this

system has no problem.

Example2)

Number of Load cell: 4pcs

Load cell capacity: 500kg

Load cell Voltage: 2mV/V

Digit: 0.10kg

Affirmation Voltage of Load cell: 5V

Max Capacity of Weighing System: 1,000kg

Then, estimation result for this weighing system with formula,

$$\frac{5000 \times 2 \times 0.10}{500 \times 4} = 0.5 \ge 0.2 \,\mu\text{V}$$

The calculated value is larger than 0.2μ V,

so this system has no problem.

5. SET-UP

5-1. Calibration

Calibration is the process of adjusting weight balance between "Real weight" on the load cell and "Displayed weight of Indicator". When you replace LOAD CELL or Indicator, you have to do Calibration process once again

5-2. Test Weight Calibration Mode (Using Test weight)

Prepare the test weight as at least 10% of your weighing scale's max capacity.

Remove "CAL-BOLT" on the indicator's front panel and press "CAL - LOCK S/W" inside.


**Remark: If "P-W" is displayed, you should input the pass word to start calibration mode.

1. At normal mode, remove "CAL-BOLT" on the Front panel



2. And press "CAL - LOCK S/W" inside.

Check the "SET-CAL. message on display.



※ To save the each step, press



key, and for the cancel or move back, press



key.

ENTER



key, Calibration Mode starts.

After displaying "C999999",



4. Input the max capacity of your weighing scale,



3. If you press



Ex) Load cell CAPA: 20kg, division: 0.001 → Input 20000



5. Define the optimal position of decimal point.

Whenever you press will be changed.




key, the location of decimal point

key, the location of dec

Ex) Load Cell CAPA: 20kg, division: 0.001kg → input 20.000







12. Input the weight of your "Test weight". And press

Ex) Load Cell CAPA: 20kg, division 0.001

- → Use test weight which is at least 10% of


 max CAPA(20kg) = minimum 2kg of test weight is needed.
- → Input test weight 2.000 to indicator.
- 13. When "UP" is displayed, load your test weight on the scale (weigh bridge) Ex) Load Cell CAPA: 20kg, division 0.001



- 14. And press key.
- → Do not remove the test weight from weigh bridge.



15. Indicator will calculate span value during 5sec.



16. After finish calculation, span value will be displayed.
Please remove the test weight from weigh bridge.



*** Caution:** The "Test Weight's value" must be at least 10% Max capacity of weighing scale.



"at least 10%" means to guarantee precise weighing process you have to make standard with at least 10% of the max capacity weight.

We programmed the calibration will not be done, when you load less than 10% of the max capacity.

17. Press key to save all calibration process.

After then it resets automatically.

Now, fasten the Calibration Bolt on the front panel.

5-3. Simulation Calibration Mode (Calibrate without Test weight)

Through this "Simulation Calibration Mode" you can do simple calibration process without Test weight.

This calibration mode uses "Load cells' max capacity" and "Rated output value(mV)".


Simulation calibration's degree of accuracy is lower than test weight calibration.

By simulation calibration's characteristic, measured weight can be different with actual weight, according to load cell's actual output.

1. At normal mode, remove "CAL-BOLT" on the Front panel



And press "CAL - LOCK S/W" inside.
 Check the "SET-CAL. Message on display.





key, to start Simulation Calibration Mode



※ To save the each step, press



key, for the cancel or move back, press



key.

4. Press

key to enter calibration mode.

After "CAPA" is displayed, Check the max Capacity of your load cell.

(Refer the label on the load cell, or test report.)



5. After input max capacity of your load cell (at the label),



Ex) Load cell CAPA: 30kg, division: 0.01 → Input 3000



In case of multiple pieces of load cells are installed, make sum of each load cell's capacity and make setting with max capacity. EX) There are 4pcs of load cells, and each load cell's Max capa is1,000kg.

Then, total Max Capacity will be 4,000kg(1,000 x 4) and you have to input 4,000.

6. Define the optimal position or decimal point Whenever you press key, the location of decimal point will be changed.	P	30 <u>.</u> 00
7. Press key to save Digit / Decimal point and move to next step. Ex) Load cell CAPA: 30kg, division: 0.01 → Input 30.00	P	30,00
8. Define the optimal Digit/Division value of weighing measurement. Whenever you press key, the Digit/Division value will be changed in order of "1 → 2 → 5 → 10 → 20 → 50". Ex) Load cell CAPA: 30kg, division: 0.01 → Input division "1"	d	
9. press key to save the Digit/Division value and move to next step.	Ъ	
** Caution: (Division value /Max capacity value) cannot o If the division is so small compare with max capacity, Error m and move back to "CAPA" mode again.		
10. Under this step, measure the "DEAD Weight of Weighing Scale When you press key, the indicator starts the dead process to find "Zero" span.		dEAd
11. Indicator will search "DEAD weight" during 5seconds. After find optimal "Zero" span, step is automatically Moves to next.	[F	7L - 1 0

12. At this step input Max Output rate(mV) of load cell.



13. Input Load cell Output Rate(mV/V) (refer the load cell label)

Ex) Load cell Related output: 1.989 mV/V





**** Caution:** Due to some variation between **"Stated output rate"** and **"Real Output rate"** of load cell, there might be some weight difference after finishing calibration.

If you want to make more precise weighing process, please measure real output rate of load cell and input the measured value. Then the weight measurement will be more precise than before.

14. After inputting R.O. value, press

Calibration Bolt.

Calculated "Span value" will be displayed.



key.



15. Press key to save all calibration process and fasten the





X Caution: To process "Simulation Calibration" process, All indicator has its' own standard value of 2mV gap. So, if you replaced analogue board, you have to input standard value of 2mv gap.

And you can check the this 2mV gap value on **F96.** (Normally, the gap value is between 200,000 ~400,000)

5-4. Set-up

Set-up means set the F-function and make SI 4000 weighing controller will perform more accuracy.

(Considering external / internal environmental condition)

*Remarks: In case that "P-W" is displayed, you have input the pass word to start calibration mode.

5-4-1. Enter the Set-up Mode

1). Method: Press key for 4sec. Then you can enter "F-Test" mode. Under this mode, press No.1 key and enter the "F-function" mode.

5-4-2. F-Function Change

Under F-function mode, Whenever press key, the Function No. will be increased one by one. Increase to F-90 and return to F-01

If you move to certain function No., press f-function no. with number key and press



Ex.) If you want to call "F11-XX" directly under "F-function mode".




Then, you can call "F22-XX" directly.

5-4-3. F-Function Set Value Change

Under F-Function mode, input New set value with Number keys and press





Ex.) If you want to change the "F01-01" to "F01-02".



5-4-4. Exit "F-function" Mode



5-5. F-Function Detailed information

■ General Function Setting ("•" Factory default set value)

	Weight-Back up selection						
		0	Normal Mode				
F02	•	1	Weight Back up Mode				
	Motion Band Range setting						
	01 This is set "Steady" acceptable range of weighing part.						
E02	F03 06						
F03	06						
		50		ration ~ 50 : Strong Vibration)			
			Zero Tracking Compensation Rang	ge setting			
			Due to external causes(Temperature, wind, and				
		00	indicator will ignore the weight difference and o	-			
F04	02	ſ	For this compensation function, indicator will e	estimate the weight difference is over the			
		09	set range during fixed time period.	a within fixed time period, the "Zero" is			
			If there is large weight difference over set range breaking and will find new zero point.	e within fixed time period, the Zero is			
			Auto Zero Range setting				
			Within the "Auto Zero" range, weighing part is	steady, indicator will display current			
	00	00	weight as "Zero"				
F05			If the weighing part is not "Steady", indicator will display current weight.				
			(Auto Zero Range : ± Set value + weight unit)				
			Digital Filter setting				
			A : Frequency Filter setting value (0~3)	If "B" set value is fixed, "A" set value is			
F06	13	AB	(0 : about 200Hz/sec, 1 : about 500Hz/sec)	large, the indicator will response more			
			B : Buffer Filter setting value (1~9)	sensitive.			
			Zero /Tare key Operation mode so	election			
F07	•	0	Activate when "Steady" condition, only				
F07		1	Always activated				
			Zero key Operation Range sele	ction			
		0	Activated within 2% of Max Capacity				
		1	Activated within 5% of Max Capacity				
		2	Activated within 10% of Max Capacity				
E00		3	Activated within 20% of Max Capacity				
F08		4	Activated within 50% of Max Capacity				
		5	Activated within 100% of Max Capacity				
		6	Whenever Press "Zero" key (No Limit)				
		Cau	tion: If you set over 20%, there may be "CELL-	-Err" or displaying wrong value.			

	Tare key Operation Range selection										
	0 Activated within 10% of Max Capacity										
E00		1	Activated within 20% of Max Capacity								
F09		2	Activated within 50% of Max Capacity								
	•	3	Activated within 10	ctivated within 100% of Max Capacity							
	"Hold" Mode selection										
Peak Hold : Measure Max weight value and hold on display.											
F10	F10 1 Sample Hold: Hold current weight until "Hold Reset".										
				External Input Selec	tion						
Set Value Input 1 Input 2 Input 3 Input 4											
		0 Zero Tare Tare Reset Prin									
F11	•	1	Zero	Tare / Reset	Hold	Hold Reset					
		2	Zero	Tare / Reset	Print	Sub Print					
		3	Zero	Print	Hold	Hold Reset					
			"STEA	DY" condition check	time setting						
		01	During the set time	period, estimate weigh	ing part's "STEADY" co	ondition and display.					
F12	01	ſ	If you set small	value, indicator will ta	ake "STEADY" fast, if	f you set large value,					
		20	indicator will take '	"STEADY" slow.							
		ı	Display	y Up-date rate selectio	on (per 1sec)						
		0	238 times								
	•	1	102 times								
		2	64 times								
		3	47 times								
F13		4	34 times								
1.13		5	31 times								
		6	26 times								
		7	23 times								
		8	20 times								
	9 18 times										
			A	uto TARE Reset time	setting						
		00	Automatic "Tare" r	eset time setting							
F14	00	ſ	00 : not use								
		99	05 : after 5.0sec, Ta	are will reset.							

			Auto HOLD Reset time setting			
F15 00 00~99		00~99	Automatic "HOLD" reset time setting.			
F13	00	00~99	00 : not use, 05 : after 5.0sec, Tare will reset.			
	Auto Print Delay time setting					
		00	Auto Print Delay time setting.			
F16	5 00 J		00 : There is no Delay			
		99	30 : After 3.0sec auto print out., when the weight is steady over than Empty range.			
			Equipment No. setting			
E10	0.1	01.00	Equipment No. setting with No. key.			
F18	01	1 01~99	(01 ~99 settable)			
	"Key Tare" selection					
F19	•	0	Key Tare Not Use			
1-19		1	Key Tare Use			

■ Communication Mode setting (Serial Port 1. - Standard installed port)

Communication Frode Setting (Serial Fort 1: - Standard instance port)								
			Parity I	Bit selection Mode				
	•	0	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Non)			
		1	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)			
		2	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)			
F30		3	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)			
		4	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)			
		5	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)			
		6	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)			
			Serial Commu	nication Speed selection				
		0	2,400bps					
		1	4,800bps					
	•	2	9,600bps					
		3	14,400bps	14,400bps				
F31		4	19,200bps					
F31		5	28,800bps					
		6	38,400bps					
		7	57,600bps					
		8	76,800bps					
		9	115,200bps					

			DATA Transference Method selection				
F32	•	0	Simplex Mode / Stream Mode				
Г32		1	Duplex Mode / Command Mode				
			"Check-Sum" detection selection (Under F32-01 setting, only)				
F34	•	0	Check-Sum data will not be included on transferred data.				
1.24		1	Check-Sum data will be included on transferred data.				
	Serial Port Application Selection (Under F32-00 setting, only)						
F35	•	0	DATA Transference purpose				
133		1	Printing purpose (Serial Printer)				
		DA'	TA Transference Mode selection (Under F32-00, F35-00 setting, only)				
	•	0	Stream Mode: Weighing Data will be transferred continuously.				
F36		1	Steady Mode: When the Weight is steady over than EMPTY				
1.30		1	※ F-80 : EMPTY Range setting				
		2	Manual Mode: When "Print" key input, 1 time transferred.				
		DAT	TA Transference Format selection(Under F32-00, F35-00 setting, only)				
	•	0	Format 1.				
F37		1	Format 2. (Format 1 + ID No.)				
137		2	CAS Format				
		3	AND Format				
	T		Print Mode selection (Under F32-00, F35-01 setting, only)				
	•	0	Manual Print : Whenever "Print" key input.				
F38		1	Auto Print : When the Weight is steady over than EMPTY				
			※ F-80 : EMPTY Range setting				
			Transferred Weight DATA Byte selection				
F40	•	0	7 Byte data Transfer				
		1	8 Byte data Transfer				

^{**}CAS format DATA transference(F37-02) only applies 7byte.

■ Print Mode Setting (These settings will be apply to Serial and Parallel print)

	Weight Unit selection						
	•	0	kg				
F41		1	g				
		2	t				
	Print Format selection (If you install on Standard Serial Port)						
F42	•	0	Continuous Print : Serial No. and Weight will be printed continuously.				
Г42		1	Single Print : Date, Time, S/N, ID No. Weighing Data will be print				

			SUB/GRAND Total Data Delete selection				
			Manual Delete Mode				
	•	0	SUN Total Delete : "Clear" key + "P/N" key				
F44			GRAND Total Delete: "Clear" key + "S/N" key				
			Automatic Delete Mode				
		1	After SUB/GRAND Total Print, Automatically Deleted.				
			Paper Withdraw Rate setting (After SUB/GRAND Total Print)				
F45	00	00~09	Whenever set value increased, 1line will be added.				
			Paper Withdraw Rate setting (After Continuous/Single Print)				
F46	00	00~09	Whenever set value increased, 1line will be added.				
		P	rinting Language Selection (If you install on Standard Serial Port)				
E47	•	0	KOREAN				
F47		1	ENGLISH				
			Minus(-) symbol Print selection				
F49	•	0	Print minus(-) symbol, if the weight is minus(-).				
1'47		1	Ignore minus(-) symbol				
			Function / Clear key Activation display selection				
F51	•	0	Activation display not use				
131		1	Activation display use				
			Communication Interval Setting				
F53	•	0	Fast Speed (The interval is short)				
133		1	Low Speed (The interval is long)				
			Analogue Output Setting (4~20mA / Option)				
F54	•	0	Positive Output (Max Capacity : 20mA output)				
131		1	Negative Output (Max Capacity : 4mA output)				
			Pass Word Using setting (F95 Change Password)				
F55		0	Not used				
133		1	Using				
			Protocol Frame Transit Setting				
	•	0	Not Used				
F56		1	Using (When connecting protocol with an appliance which uses frame by frame.)				
	Caution: When setting Command frame, if F53(protocol frequency) is high the speed of system can						
		be slow	. In this case, please set F53-01.				
			BCD INPUT Type Setting (Refer to Interface BCD INPUT)				
F57	•	0	Input the units digit & the tens digit one by one. (1,2,4,8)(1,2,4)				
101		1	Input the units digit & the tens digit together (1,2,4,8,16,32)				

	Print Format Setting (Refer to Print Interface)					
	•	0	Format 1			
F58		1	Format 2(Under F42, There is no division about continuous print or single print)			
			Format3(Net gross print)			

■ Other Setting

	-	EMPTY Range setting						
		You can set "EMPTY" Range. Within set range, indicator will not display current						
E00	X.X.X.X.X.	weight and just display "Zero".						
F80	(0.0.0.0.1.0)	"0.000" setting: When Net Zero, "Zero" status lamp and Near Zero relay will be output.						
		"0.190" setting: Within 190, "Zero" Status lamp and Near Zero relay will be output.						
	Minimum Analog Output Setting							
F81	•	output value is able to adjust to be 4mA or 0V. (Minimum value is 0)						
	Number key '1': N	Move to left, '2': Move to right, '3': Increase value						
		Maximum Analog Output Setting						
F82	•	output value is able to adjust to be 20mA or 10V. (Maximum value is 65536)						
	Number key '1': N	Move to left, '2': Move to right, '3': Increase value						
		SPAN Calibration Value Check						
		Span Calibration Value Check						
	X.X.X.X.X.	Under F-function mode, enter "SUB", "9" key and press "CLEAR".						
		Under F-function mode, enter , key and press .						
F89		After checking the value and press "CLEAR" to exit						
		* If you have difficulty to process Calibration again, the best way to matching the						
		net weight and display weight is doing Calibration process once again.						
		DATE Check / Change						
F90	Check Current DA	TE data or you can Change to new date						
		TIME check / Change						
F91	Check Current TIN	ΛΕ data or you can Change to new date						
		SETUP Mode Password Key Setting / Change						
	How to set :" If "P	-W" display, input the previous saved password . Then,						
F95	"1" display: inj	out 4 numbers, "2" display: input the 4 numbers once more. (recheck the password)						
	Factory default set value: 0000 Please don't forget your pass word.							
		Program & Hard ware Version Check						
F98	Check the Program	a & Hard ware version (H/W : X.XX, S/W : X.XX.X)						
		Production DATE Check						
F99	Check the Product	's Production Year and Month.						

■ Communication Mode setting (Serial Port 2. - Optional Serial port)

		Parity Bit	selection Mode					
	• 0	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Non)				
	1	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)				
	2	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)				
F60	3	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)				
	4	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)				
	5	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)				
	6	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)				
		Serial Communi	ication Speed selection					
	0	2,400bps						
	1	4,800bps						
	• 2	9,600bps						
	3	14,400bps						
F61	4	19,200bps						
L01	5	28,800bps						
	6	38,400bps						
	7	57,600bps						
	8	76,800bps						
	9	115,200bps						
		DATA Transfer	ence Method selection					
F62	• 0	Simplex Mode / Stream Mode						
102	1	Duplex Mode / Command Mod	de					
		"Check-Sum" detection sel	ection (Under F62-01 setting,	, only)				
F64	• 0	Check-Sum data will not be in	cluded on transferred data.					
101	1	Check-Sum data will be include	led on transferred data.					
	DA	TA Transference Mode selecti	on (Under F62-00, F65-00 se	tting, only)				
	• 0	Stream Mode: Weighing Data will be transferred continuously.						
F66	1	Steady Mode: When the Weight is steady over than EMPTY						
	2 Manual Mode : When "Print" key input, 1 time transferred.							
	DAT	TA Transference Format selec	tion(Under F62-00, F65-00 se	etting, only)				
	• 0	Format 1.						
F67	1	Format 2. (Format 1 + ID No.)						
	2	CAS Format						


6. INTERFACE

6-1. Serial Interface (RS-232C)


RS-232C Serial Interface is sensitive/weak for electric Noise.

So, please isolate with AC power cable and use shield cable to reduce the electric noise effect.

6-1-1. Communication with PC(Personal Computer) or Other devices



6-1-2 RS-232C Circuit



6-1-3. Signal Format

- ① Type: EIA-RS-232C
- ② Communication Method: Half-Duplex, Full Duplex, Asynchronous
- ③ Serial Baud Rate: Selectable on "F-function31"
- ① Data Bit: 8(No Parity mode, only)Bit Refer "F30".
- ⑤ Stop Bit: 1
- 6 Parity Bit: Non, Even, Odd (Selectable on "F-function 30") Refer "F30"
- 7 Code: ASCII


STX 02H

ETX 03H


CR 0DH

LF 0AH

(8) Check-Sum (Error Detecting, "F-Function 34")



6-1-4 Data Format(1): ID Number will not be transferred. (Refer "F-function 37")



1 Header 1.: OL: Over Load, Under Load

ST: Display weight "Steady"

US: Display "Un-Steady"

② Header 2.: NT: Net-Weight

GS: Net-Weight, under TARE

3 Data Bit(Number) 2B(H): "+" Plus


2D(H): "-" Minus

2D(H): " " Space

2E(H): "." Decimal Point

4 Unit: kg, g, t

6-1-5 Data Format(2): ID Number + Data Transference (Refer "F-function 18, 37)



① Header 1.: OL: Over Load, Under Load

ST: Display "Steady"

US: Display "Un-Steady"

② Header 2.: NT: Net-Weight

DIGITAL WEIGHING INDICATOR SI 4010

GS: Net-Weight, under TARE.

3 Data Bit(Number) 2B(H): "+" Plus


2D(H): "-" Minus

2D(H): "" Space

2E(H): "." Decimal Point

4 Unit: kg, g, t

6-1-6 Data Format(3): CAS "CI5101A" Data Transference) - CAS 22byte Format



1 Header 1. : OL : Over Load, Under Load

ST: Display "Steady"

US: Display "Un-Steady"

② Header 2.: NT: Net-Weight

GS: Net-Weight, under TARE.

3 Lamp Display : Current Lamp Condition (ON/Off Data)

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	Steady	1	Hold	Print	Gross Weight	Tare	Zero

4 Data Bit(Number) 2B(H): "+" Plus

2D(H): "-" Minus


2D(H): " " Space

2E(H): "." Decimal Point

5 Unit: kg, g, t

DIGITAL WEIGHING INDICATOR SI 4010

6-1-7. Data Format: AD - 4321 Data Transference) - AD - 4321 18byte Format



1 Header 1.: OL: Over Load, Under Load

ST: Display "Steady"

US: Display "Un-Steady"

② Header 2.: NT: Net weight (Under Tare)

GS: Net weight (Under TARE reset)

3 Data Bit(Number) 2B(H): "+" Plus

2D(H): "-" Minus

20(H): " " Space

2E(H): "." Decimal Point

4 Unit: Kg, g, t


6-2. Current Loop Interface

"Current Loop" Interface is stronger for Electric Noise than "RS-232C" interface.

So, it can be used for long distance communication.(About 100m long distance).

X Current Loop Interface supports, up to 9,600 Communication Speed, only.


6-2-1. Communication with Other Devices (Remote Display / External Display)



Remote Display
(External Display)

SI 4010

6-2-2. Current Loop Circuit



6-2-2. Data Format

As same as "RS-232C" Interface

6-3. Analog Output Interface (Option 02: 0~10V Output)


This Option card converts weight value to Analog Voltage output(0~10V) and transfers to external devices(Recorder, P.L.C), controlled by voltage output.

6-3-1. Specification

①. Output Voltage: 0~10V DC output

2. Accuracy: More than 1/1,000

6-3-2. Circuit



* This Voltage output is proportioned on weight calibration and outputs 0~10V.

6-3-3. Output Adjustment


- ①. This output is adjusted as when the weight is "Zero", output is 0V and When the weight is "Full capacity", output is 10V.
- ②. If you need additional adjustment, please adjust with "VR1(Zero)", "VR2(Span) on the Analog Output PCB.

***** Remark

This Analog option card converts Displayed weight value(Micro-process data) to analog value on D/A Converter(Digital to Analog converter)

This D/A Converter has Max 1/4,000 accuracy, so this output is not suitable for high accuracy application, like more than 1/3,000.

6-4-4. Connecter (9pin, "D-type" female)



* For 0~5VDC or 1~5VDC analog output, please inform when you inquiry.

6-4. Analog Output Interface (Option 03: 4~20mA Output)

This Option card converts weight value to Analog Electric Current output(4~20mA) and transfers to external devices(Recorder, P.L.C), controlled by electric current output.

6-4-1. Specification

①. Output Current : 4~20mA (Output Range : 2~22mA)


2. Accuracy: More than 1/1,000

③. Temperature Co-efficiency : 0.01% °C

4. Max Loaded Impedance : Max 500Ω

When Weight display is "Zero", 4mA current will be output, when Weight display is "Full Capacity", 20mA current will be output.

6-4-2. Circuit



* "LO" terminal is not a "GND", so this "LO" terminal do not be connected with other "GND" terminal on other devices.

6-4-3. Output Adjustment

- ① This output is adjusted as when the weight is "Zero", output is "4mA" and When the weight is "Full capacity", output is "20mA".
- ② If you need additional adjustment, please adjust with "VR1(Zero)", "VR2(Span) on the Analog Output PCB.

***** Remark

This Analog option card converts Displayed weight value(Micro-process data) to analog value on D/A Converter(Digital to Analog converter)

This D/A Converter has Max 1/4,000 accuracy, so this output is not suitable for high accuracy application, like more than 1/3,000.

6-4-4. Connecter (9pin, "D-type" female)

9 pin D-type connector(Female)	Terminal Block (3 pin)
1: HI(+), 5: (-)	2:NC 1:HI(+) 3:(-)

6-5. Serial Interface (option 04 : RS-232C/422/485)

RS-422/485 serial interface is more stable for electric noise effect compare with other communication method, using electric current difference.

But, install isolated place from Power cable or other electric cables and wires, and please use shielded cable for better performance.

Recommendable communication distance is about 1.2km.

If you install additional RS-232C interface, please refer "6-1. Serial Interface" section.

6-5-1. Signal Format

①. Type: RS-422/485

2. Format: Baud Rate: Refer "F-function 31".

Data Bit: 7 or 8(No Parity)

Stop:1

Parity Bit: Even, Odd, No Parity (Selectable)

Code: ASCII (STX 02H, ETX 03H, CR 0DH, LF 0AH)



Potential Difference

6-5-2. Data Format

Same as RS-232C (Refer "6-1. Serial Interface")

6-5-3. RS-485 Circuit (In case of RS-485, only Use No6 and 7 pin)


D-SUB 9 pin In case of RS -232 : "6-1. Refer to Serial Interface" In case of RS-485 : only Use No6 and 7 pin			Termi	nal Block
TXD (-) TXD (+) RXD (-) RXD (+)	TXD (-) 9 TXD (+) 8 + RXD (-) 7			3 4
Terminal Block	1	2	3	4
RS-232	TX	RX	GND	GND
RS-485	RTX+	RTX-	NC	NC
RS-422	RXD+	RXD-	TXD+	TXD-

6-6. BCD Input (Option 05) – Input for Part No. selection.


This "BCD interface" option card can be applied on PLC (Programmable Logic Controller), or Score Board applications.

Each Input circuit is isolated with "Photo-Coupler", from external devices electrically for the efficiency.

→Setting F57-00




→Setting F57-01




6-7. BCD Output Interface(Option 06)

This "BCD interface" option card can be applied on PLC (Programmable Logic Controller), or Score Board applications.(NPN TYPE)

Each Input circuit is isolated with "Photo-Coupler", from external devices electrically.





F-function setting for BCD OUT				
F - No.	Set value	F - No.	Set value	
F30	0	F60	0	
F31	2	F61	2	
F32	0	F62	0	
F33	0	F63	0	
F34	0	F64	0	
F35	0	F65	0	
F36	0	F66	0	
F37	0	F67	0	
F38	0			

6-8. Print Interface

6-8-1. Print Format < 30 Column only. > Format 1 (F58-00)

Single Print Format

Date: 2008-05-10					
Time	: 14:38:33				
P/N	Code	S/N	Weight		
04	000001	1	1.000kg		
====	=======	=====	=======		
Date	Date: 2008-05-10				
Time: 14:40:33					
P/N	Code	S/N	Weight		
04	000001	2	1.000kg		
٠.	000001	_	1.000kg		

Sub-Total Print Format

Sub-Total				
Date: 2008-05-10				
Time: 14:38:33				
Part Number:	04			
Total Count:	10000			
Total Weight:	10000.000kg			

Format 2 (F58-01)

	====	
DATE,TIN	ЛE : (09-10-26 14:43:39
SERIAL	:	01
GROSS	:	3,000 kg
TARE	:	1,000 kg
NET	:	2,000 kg
	====	

Continuous Print Format

Date: 2008-05-10				
Time	: 14:38:33	3		
P/N	Code	S/N	Weight	
04	000001	1	1.000kg	
04	000001	2	1.000kg	
04	000001	3	1.000kg	
04	000001	4	1.000kg	
04	000001	5	1.000kg	
04	000001	6	1.000kg	
04	000001	7	1.000kg	

Grand-Total Print

	<u> </u>			
	Grand	-Total		
Date : 20	008-05-10			
Time: 14	4:38:33			
PART	PART SERIAL TOTAL-W			
04	5	500.000kg		
Total Part: 04				
Total Count: 10000				
Total Weight: 10000.000kg				

Format 3 (F58-02)				
Date:	2010.09.	15		
17:30	NET:	218 kg		
17:31	NET:	716 kg		
17:32	NET:	717 kg		
17:33	NET:	717 kg		
17:34	NET:	717 kg		
17:35	NET:	717 kg		
17:36	NET:	717 kg		
=======================================				
TOTAL: 26450 kg				

6-9. Command Mode

6-8-1. Read Command (Standard Serial Port and Optional Port is same.)

Current weight				
ASCII : STX ID(2By	ASCII : STX ID(2Byte) RCWT ETX HEX : 02 30 31 52 43 57 54 03 (ID No.: 01)			
	STX ID NO. RCWT State1(2byte), State2(2byte),+/- Current weight (7/8byte)			
Weight unit (2byte) ETX				
SI4010 REPONSE	State1: OL(Over load), ST(Ste	eady), US(Unsteady)		
	State2: NT(Gross weight), GS(Net weight)		
	Indicator M	emory Data		
ASCII : STX ID(2By	te) RCWD ETX	HEX : 02 30 31 52 43 57 44 03 (ID No. : 1)		
SI4010 REPONSE	STX ID NO. RCWD date (6byte	e) time (6byte) P/N(2byte) S/N(6byte) Tare value		
SI4010 REI ONSE	(7/8byte) Current weight (7/8by	yte) Weight unit (2byte) ETX		
	SUB-To	tal Data		
ASCII : STX ID(2By	te) RSUB ETX	HEX : 02 30 31 52 53 55 42 03 (ID No. : 1)		
SI4010 REPONSE	STX ID NO. RSUB P/N(2byte)	Accumulated sub-total Count (6byte) Accumulated		
SI4010 REI ONSE	weight value(11byte) Weight un	nit (2byte) ETX		
	GRAND T	Fotal Data		
ASCII : STX ID(2By	te) RGRD ETX	HEX : 02 30 31 52 47 52 44 03 (ID No. : 1)		
SI4010 REPONSE	STX ID NO. RGRD P/N(2byte) Accumulated count (6byte) Accumulated weight			
211010 1111 01182	(11byte) weight unit (2byte) ETX			
	S/N Data (Accu	umulated Data)		
ASCII: STX ID(2By	te) RSNO ETX	HEX : 02 30 31 52 53 4E 4F 03 (ID No.: 1)		
SI4010 REPONSE	REPONSE STX ID NO. RSNO Accumulated count (6byte) ETX			
	Curre	nt Time		
ASCII: STX ID(2By	te) RTIM ETX	HEX : 02 30 31 52 54 49 4D 03 (ID No. : 1)		
SI4010 REPONSE	STX ID NO. RTIM Current	Time (6byte) ETX		
	Current 1	Date Data		
ASCII : STX ID(2Byte) RDAT ETX HEX : 02 30 31 52 44 41 54 03 (ID No. : 1)		HEX : 02 30 31 52 44 41 54 03 (ID No. : 1)		
SI4010 REPONSE STX ID NO. RDAT Current Date (6byte) ETX		Date (6byte) ETX		
Tare Data				
ASCII : STX ID(2Byte) RTAR ETX HEX : 02 30 31 52 54 41 52 03 (ID No. : 1)				
SI4010 REPONSE	STX ID NO. RTAR Tare Da	ta (7/8byte) ETX		
	P/N Data			
ASCII : STX ID(2By	ASCII : STX ID(2Byte) RPNO ETX HEX : 02 30 31 52 50 4E 4F 03 (ID No. : 1)			
SI4010 REPONSE	STX IN NO. RPNO P/N Set value(2byte) ETX			

6-8-2. Write Command

	To make Current Weight as Zero			
ASCII : STX ID(2Byte) WZER ETX		HEX : 02 30 31 57 5A 45 52 03 (ID No.: 01)		
SI4010 response	Normal : ACK	Error: NAK		
	TA	RE		
ASCII : STX ID(2Byt	e) WTAR ETX	HEX : 02 30 31 57 54 41 52 03 (ID No.: 01)		
SI4010 response	Normal : ACK	Error: NAK		
	TARE	E Reset		
ASCII : STX ID(2Byt	e) WTRS ETX	HEX : 02 30 31 57 54 52 53 03 (ID No.: 01)		
SI4010 response	Normal : ACK	Error: NAK		
	TIME Setting			
ASCII : STX ID(2Byte) WTIM Time data(6byte) HEX : 02 30 31 57 54 49 4D 31 32 30 30 30		HEX : 02 30 31 57 54 49 4D 31 32 30 30 30 30 03		
ETX		(ID No.: 01)(Time data: 12:00:00)		
SI4010 response	Normal : ACK	Error: NAK		
	DATE	Setting		
ASCII : STX ID(2Byt	e) WDAT	HEX : 02 30 31 57 44 41 54 30 39 30 39 30 34 03		
Time da	ata (6byte) ETX	(ID No.: 01)(Time data: 09/09/04)		
SI4010 response	Normal : ACK	Error: NAK		
P/N Change				
ASCII : STX ID(2Byt	e) WPNO	HEX : 02 30 31 57 50 4E 4F 31 31 03 (ID No. :		
]	P/N data (2byte) ETX	01)(P/N data : 11)		
SI4010 response	Normal : ACK	Error: NAK		

• How to Calculate Check sum.

Sum the value from "STX" to "ETX" and converts to ASCII(2byte) and transfer.

Convert the Sum value(HEX) to ASCII and transmit(28byte) .

ex) The sum HEX value from STX to ETX(02,30,31,52,43,57,54,03) is 1A6h.

Then, divide 1A6h by 100h(1A6h/100h). the rest of result is A6h.

Calculated remainder value is A6h, then convert A6h to ASCII, 41(A), 36(6), and transfer.

7. Error & Treatment

7-1. Load Cell Installation

Error	Cause	Treatment	Remark
Weight Value is unstable	1.oad cell broken 2.oad cell isolation resistance error 3.eighing part touches other devices or some weight is on the weighing part 4.Suming Board Error	1.Measure input/output resistance of Load cell. 2.Measure Load cell isolation resistance 3.Check attach point with other devices.	1. Input Resistance of "EXC+" and "EXC-" is about $400\Omega \pm 30$ 2. Output Resistance of "SIG+" and "SIG-" is about $350\Omega \pm 3.5$ 3. Isolate Resistance is more than $100M\Omega$
Weight Value is increased regular rate, but not return to "Zero" Weight Value is	1.oad cell Error 2.oad cell Connection Error	1.Check Load cell connect 2.Measure Load cell Res	
increased to under Zero	Load cell Output wire (SIG+, SIG-) is switched	Make wire correction	
"UN PASS"	Load cell broken or Indicator connection Error	Load cell Check Load cell connection Che	eck
display	Power was "ON" when some weight is on the load cell?	Remove weight on the Lo	oad cell
"OL" display	1.ad cell broken or Indicator connection Error 2.oading over than Max Capacity	Load cell Check Load cell connection C semove over loaded wei	

7-2. Calibration Process

Error	Cause & Treatment		
Err 01	When {Maxcapacity/digit} value is over 20,000		
Err 04	Standard weight value is over than Max Capacity		
Err 05	Standard weight value is less than 10% of Max Capacity		
Err 06	1. Amp. Gain is too big 2. Sig+ and Sig- wire connection error 3. Test weight is not loaded		
Err 07	1. Amp. Gain is too small 2. Sig+ and Sig- wire connection error 3. Test weight is not loaded		
Err 08	Under "F-function" mode, set value is "N.A"		
Err A	When there is continuous vibration on the weighing part,, indicator cannot process calibration.		

7-3. Digital Weighing Indicator

Error No.	Display	Cause	Treatment
No.1	"CELL- Er" or "OL"	1. Load cell Error 2. Load cell cable Error 3. Load cell connection Error 4. A/D Board Error	1. Under "TEST" mode 1, check analogue value. If you cannot get any analogue value or there is no change although adding load, please check load cell, load cell cable, connection conditions first. 2. Replace another load cell, and check the indicator condition. If you have same problem, please replace new indicator and check A/D board error.
No.2	"Un- Pass"	 Power is ON, when some materials are on weighing part. Under "Normal Mode", if there are more than 20% loading of Max capacity, "Un-Pass" display will be appeared and indicator will stay until removing the load. 	1. If you set "Normal Mode", please check weighing part empty or not before turn on the power. If there are some materials in/on weighing part, please remove those materials and turn on the power.
No.3	"FN SET"	When "FN-Memory" is defected When the "FN-Memory" is empty.	Please contact the distributor or Head Office.
No.4	"P-Err"	Under Parallel Printer is connected and installed. 1. Parallel printer interface is defected or disconnected.	Please check connection of the print cable. Please check the trouble of print. If you only install "Parallel Print" option card, you can check to do.

^{**} Under "CELL-Er", Relay will not be Output, and Analogue Output(4~20mA/0~10V), either.

7-4. Indicator Test mode

Through this "Test Mode", you can check basic conditions of Indicator.

This Test consist with total 7 tests.

7-4-1. Enter "Test Mode"



key for 4sec, then display will show "F-Test".

Under this display, press No.2 key and enter the "Test Mode".

Under "Test Mode", please choose each test and check the basic conditions of Indicator.



If you want to exit from each "Test Mode", press

7-4-2. Test Mode

Test Mode	Contents		
Test 1. Analogue Value Test (F-KEY: Zero, 1-KEY: Return)	Under "TEST" display, press No.1 key and Enter "TEST1" mode. Under this mode, you can check the A/D value. If the A/D value is unstable, or there is no change although pressing or loading some force on/in weighing part, please check load cell, load cell, cable, connecter, A/D board.		
Test 2. Key test	Under "TEST" display, press No.2 key and Enter "TEST2" mode. Press each key, and check the pressed key is operated.		
Test 3. Output Relay Test	Under "TEST" display, press No.3 key and Enter "TEST3" mode. This Test will be operated automatically from Relay1 to Relay6. ** This test will operate automatically, so please remove all materials in/on weighing parts. If you can not remove materials, please remove relay terminals.		
Test 4. External Input Test	Under "TEST" display, press No.4 key and Enter "TEST4" mode. If you press External input S/W, the External S/W No. will be displayed. If the S/W No. is not displayed, please check connecting condition.		

Under "TEST" display, press No.5 key and Enter "TEST5" mode. Test 5. After connecting No.2 and 3 pin of 9pin connector, you can test communication condition, like TXD or RXD/TXD. Communication **Test** If there is an error in communication, "232-Err" will be displayed with 3times buzzer sound. The communication is working properly, "232Pass" will be displayed with one (Com. Port 1) time buzzer sound. Under "TEST" display, press No.6 key and Enter "TEST6" mode. Test 6. After connecting No.2 and 3 pin of 9pin connector, you can test communication condition, Communication like TXD or RXD/TXD. If there is an error in communication, "232-Err" will be displayed with 3times buzzer **Test** (Com. Port 2) sound. The communication is working properly, "232Pass" will be displayed with one time buzzer sound.

WARRANTEE CETIFICATION

This product is passed "Sewhacnm"s strict quality test.

If there is defect of manufacturing or abnormal detection within warrantee period, please contact our Agent or Distributor with this Warrantee certificate.

Then, we will repair or replace free of charge.

WARRANTEE CLAUSE

1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date

2. Warrantee Exception Clause

- Warrantee period is expired.
- Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm's permission.
- Any kinds of Mal-function, Defection, or External damage, caused by operator
- Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent.
- Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this
- Any kinds of Mal-function, Defection caused by "Force Majeur", like Fire, Flood.
- Without presentation of this "Warrantee Certification".

3. Other

- Any kinds of "Warrantee Certification" without authorized Stamp is out of validity

Manufacturer : SEWHACNM Co.,Ltd.	Product	Digital Weighing Indicator
#504, 302Dong, 397, Seokcheon-ro, Ojeong-gu,	Model	SI 4010
Bucheon-si, Gyeonggi-do, Korea	Serial No.	
Tel: +82 70) 4754 6140		
Fax :+82 32) 624 0065	AUTHORIZED STAMP	Sewha CNM Co.,Ltd
sales@sewhacnm.co.kr		
http://www.sewhacnm.co.kr		
Made in KOREA		