

Digital Weighing Controller SI 4200

Instruction Manual





CONTENTS

1. Before Installation	 3 page
2. Introduction	 4 page
3. Specification	 5 page
4. Installation	 11 page
4-1. External Dimension & Cutting Size	 11 page
4-2. Load Cell Installation	 11 page
4-3. Installation Components	 12 page
5. Set-up	 14 page
5-1. Calibration	 14 page
5-2. TEST Weight Calibration Mode	 14 page
5-3. Simulation Calibration Mode(Without Test Weight)	 17 page
5-4 Unit Calibration Mode	 20 page
5-5. F-Function Setting	 22 page
5-6. F-Function List	 23 page
6. Interface	 35 page
6-1. Serial Interface (RS-232C)	 35 page
6-2. Current Loop Interface	 39 page
6-3. Print Interface (Option 01 : Centronics Parallel Interface)	 40 page
6-4. Analog Output Interface (Option 02 : 0~10V)	 42 page
6-5. Analog Output Interface (Option 03 : 4~20mA)	 43 page
6-6. Serial Interface (Option 04 : RS-232C / 422 / 485)	 44 page
6-7. BCD INPUT (Option 05)	 45 page
6-8. BCD OUTPUT (Option 06)	 46 page
6-9. Command Mode	 47 page
7. Error & Treatment	 49 page
7-1. Load Cell Installation	 49 page
7-2. Calibration Process	 49 page
7-3. Indicator Error & Treatment	 50 page
7-4. Indicator Test Mode	 51 page
Warrantee Certification	 52 page

1. BEFORE INSTALLATION

1-1. Caution / Warning Marks

	This mark warns the possibility to arrive death or serious injury in case of wrongly used.
<u>Caution</u>	This mark cautions the possibility to arrive serious human body injury or product lose in case of wrongly used.

1-2. Other Marks

	Warning for Electric Shock or Damage. Please do not touch by hand	
÷	Protective Ground(Earth) terminal	
	Prohibition of Operation process	

1-3. Copy Rights

1). All Right and Authority for this Manual is belonged to Sewhacnm Co., Ltd.

2). Any kinds of copy or distribution without Sewhacnm Co., Ltd's permission will be prohibited.

1-4. Inquiries

If you have any kinds of inquiries for this model, please contact with your local agent or Head Office.

Head Office : Sewhacnm Co.,Ltd.

Website : <u>www.sewhacnm.co.kr</u>

Email : <u>sales@sewhacnm.co.kr</u>

2. INTRODUCTION

2-1. Introduction

Thank you for purchasing, this "SI 4200" Industrial Digital Weighing Controller.

This "SI 4200" model is advanced model for "Quantity Control application", with **2ports serial port interfaces** and precise weighing control system, you can upgrade your weighing process.

This "SI 4200" Weighing Controller is suitable for any kinds of Weight Capacity with Counting by "Unit Weight Calibration".

Enjoy your process with "SI 4200" Weighing Controller.

2-2. Cautions



1) Don't drop on the ground or avoid serious external damage on item.

2) Don't install under sunshine or heavy vibrated condition.

- 3) Don't install place where high voltage or heavy electric noise condition.
- 4) When you connect with other devices, please turn off the power of item.
- 5) Avoid from water damage.
- 6) For the improvement of function or performance, we can change item specification without prior notice or permission.

7) Item's performance will be up-dated continuously base on previous version's performance.

2-3. Features

- 1) All Modules and Option Cards are isolated to maximize accuracy and performance.
- 2) External input terminal inside.(4pcs:Can be set by F11 mode)
- 3) By using "Photo-Coupler" on each module(Option, Analog board, In/Out), we improved "Impedance problem", "Isolation ability among inputs", "Leading power problem", and "Noise covering function".
- 4) Data back-up function, when the sudden power off.
- 5) "Set value Error" check function added. Check "Set values for each weighing mode".

- If there is any wrong set value, "E" will be display and will not start weighing process

- 6) Polycarbonate film panel, strong for dust and water.
- 7) Weight Unit selection Function added. ("g", "kg", "t" selectable F40)
- 8) Variable options(Order in advance, Refer Chapter 6. Interface) "RS-232C" Standard installed.
- 9)2port Serial Interface available various applications are available.
- 10) Simulation Calibrate mode added (Can calibrate without Test weight)

3. SPECIFICATION

3-1. Analog Input & A/D Conversion

Input Sensitivity	0.2µV / Digit	
Load Cell Excitation	DC 10V (- 5V ~ + 5V)	
Max Input Signal	Max3.2mV/V	
Townsecture Coofficient	[Zero] ±16PPM/°C	
Temperature Coefficient	[Span] ±3.5PPM/°C	
Input Noise	±0.3/Å P.P	
Input Impedance	Over 10 ^{MQ}	
A/D Conversion Method	Sigma-Delta	
A/D Resolution(Internal)	520,000 Count(19bit)	
A/D Sampling Rate	Max 500times / Sec	
Non-Linearity	0.005% FS	
Display Resolution(External)	1/20,000	

3-2. Digital Part

Display	Parts Specification		
	Main Dienlay	7Segments, 7digits VFD green Color	
	Main Display	Size :12.7(H) ×7.0(W)mm	
		7Segments, 6digits FND, Red Color	
Display	Sub-Display	Size : 9.2(H) ×4.8(W)mm × 3lines	
	Min. Division	$\times 1, \times 2, \times 5, \times 10, \times 20, \times 50$	
	Max display value	+999,950	
	Under Zero value	"-" (Minus display)	
Status lamp	Steady, Zero, Tare, RUN, LIMIT, Print, Comm.	" ▼" Condition display Lamp	
	kg, g, t / SP1, SP2	Red / Yellow-Green LED Display(3Ø)	
K e y	Number Key, Function, CAL. Lock key (14pcs)		

3-3. General Specification

Power Supply	ly AC110/220V(±10%), 50/60Hz, about 30VA	
Operating Temperature Range-10 °C ~ 40 °C		
Operating Humidity Range	Under 85% Rh (non-condensing)	
External Dimension 200mm(W) × 105mm(H) × 165mm(L)		
Net Weight(kg)	About 2.3kg	
Gross Weight(kg) About 3.0kg		

* AC 110V, Power supply is an optional before ex-factory.


3-4. Option Card

Option No.1	Printer Interface : Centronics Parallel	
Option No.2	Analog Output (0~10V or 0~5V)	
Option No.3	Analog Output (4~20mA)	
Option No.4	o.4 Serial Interface : RS-232C / 422 / 485	
Option No.5	BCD INPUT (P/N change purpose)	
Option No.6	BCD Output	
Option No.7	Ethernet	

* Serial Interface (RS-232C) or Current Loop is Standard installed.

In the Optional Serial port, there is no Current Loop function

3-5. Front Panel (Display / Key Pad)



Calibration Lock-Key 3-5-1. Status Lamp (ANNUNCIATORS) : "▼" Lamp is "ON".

Unit Weight

Steady	When the weight is Steady, "▼" Lamp is turn on.		
Zero	When the current weight is Zero, "▼" Lamp is turn on.		
Zelu	(Displayed weight is Zero, "▼" Lamp is turn on.)		
Tare	Tare function is set, " $\mathbf{\nabla}$ " Lamp is turn on. (Tare Reset \rightarrow " $\mathbf{\nabla}$ " Lamp is turn off.)		
Under Packer Mode(F21-02) setting.			
RUN	Start Packer Mode \rightarrow " \checkmark " Lamp is ON		
LIMIT	Under Limit Mode(F21-01) setting. "▼" Lamp is ON.		
Print	When print key input or Auto print, "▼" Lamp is turn on.		
	When indicator transfers or receives data from other devices, " $\mathbf{\nabla}$ " Lamp is turn on.		
Comm.	(If the " $\mathbf{\nabla}$ " is off although there is some data transference, please check communication		
	settings).		

3-5-2. Key Operation

3-5-2. Key Operation			
	Make Weight value as Zero.		
1	Under F08, you can set the Zero key operation range, as 2%, or 5%, or 10%, or 20% of		
ZERO	Max Capacity.		
	* Under "Tare" key input, Zero key will not be activated.		
	Make Weight value as Zero, including Tare Weight.		
2	Under F09, you can set the Tare key operation range, as 10%, 20%, 50%, or 100% of Max		
	Capacity.		
	Tare setting : Under F10-00 setting, "TARE" key input		
	Under F10-01 setting, "Tare"+ No. key + "Enter"		
3 TARE RESET	Remove set TARE value.		
4 RUN /STOP	Under Packer Mode(F21-02), Start the packer mode process. First input is "START", Second input is "STOP"		
5 UNIT WEIGHT	Manual "Unit Weight" input Key. If you already knew the "Unit Weight", you can input "Unit weight" without calibration.		
	You can set each weighing process as a certain P/N.		
6	Each weighing process will be saved with FINAL, PRE1, PRE2, and Free Fall set		
P/N	value.(Max 50 kinds of P/N you can set)		
	And you can call certain P/N with each set value.		
7 SP1	You can set SP1 value through this key.		
8 SP2	You can set SP2 value through this key.		

Digital Weighing Indicator SI 4200

9 FREE FALL	You can set FREE FALL value through this key.
	1. Manual Print (F38-00 setting, under F35-01)
	2. Manual weighing Data save for accumulated weighing count and weight.
	(F01-00 / 02 setting)
0	3. Calibration mode
PRINT	- Digit setting
	Whenever pressing "0"key, digit will be change 1, 2, 5, 10, and 50.
	- Decimal point position
	Whenever pressing "0"key, decimal point will be change.
	1. Modify the set value during setting process.
	2. Calibration mode
CLEAR	- Move back to previous step.
GLEAR	F-function Mode.
	- F-function Exit : Press "Clear" key, once.
	- F-Test Mode Exit : Press "Clear" key, twice.
	1. Save set value during setting process.
	2. Calibration mode
ENTER	- Save current setting and move to next step.
	3. F-Function mode
	- Save current F-function setting, and move to next F-function
	1. "F-TEST" Mode Entrance : Press "F" key for 5sec.
	2. Under "F-function Mode", Move to next Function or move to certain function
	No.(Press function No. and press "F" key)
	3. Function key (Refer "Function keys")
	Enter/Exit to "Calibration" mode.
CAL.	"ON" : Enter to Calibration Mode.
	"OFF" : Exit from Calibration Mode.

* "Function Keys" (Combined Key Function)

× Fulletion	* Function Keys (Combined Key Function)			
F	5 UNIT WEIGHT	Enter "Unit Weight Calibration" mode. - Please refer "5-4. Unit Calibration".		
F	6 P/N	Print all P/Ns' accumulated weighing count and weight. (Grand-Total Print)		
F	7 SP1	High Range value setting (N.G Relay).		
F	8 SP2	Under Range value setting(N.G Relay)		
F	9 FREE FALL	Print current P/N's accumulated weighing count and weight. (Sub-Total Print)		
F	O PRINT	 Display accumulated weighing count and weight Max accumulated weight display : 21,474,839,647(g, kg, ton) Max accumulated weighing count : 999,999times * Under F15, you can set what kinds of accumulated count and weight. F15-00 : Display current P/N's accumulated count and weight. F15-01 : Display all P/Ns' accumulated count and weight 		
CLEAR	6 P/N	Delete all P/Ns' accumulated weighing count and weight (If you set F44-01, the data will be automatically deleted after "Grand-Total Print).		
CLEAR	9 FREE FALL	Delete current P/N's accumulated weighing count and weight (If you set F44-01, the data will be automatically deleted after "Sub-Total Print).		
* After Pressing key, you have to input above function keys within 5sec After 5sec, the key activation is loose				
·	* If you set "F51-01" you can check the F CLEAR (CLEAR (CLEAR)			
※ After Pressing activation wi		" key, non-function keys are input, the """, """"" key		

3-6. Rear Panel





① POWER AC IN

- Power switch : Power on/off switch.
- Fuse : AC250V / 0.5A , $\phi 5.25$, 20mm.
- AC IN : Available Input AC 110V / 220V.

****** The standard power supply is AC 220V(Fixed when ex-warehouse), if you want to have AC 110V, please inform in advance.

- ② Option Card 1
- ③ Option Card 2

* Option Card Connector installed for Optional Interface or Output.

(Printer I/F, Analog out, RS-422/485, or RS-232C(two port)

- ④ LOAD CELL Connector (N16-05)
- 5 SERIAL I/F

"RS-232C" or "CURRENT LOOP" (9Pin, D-Type Female) are built-in as standard

6 External Input : External control input for wired remote control.

Refer to F-Function F11 to select desired function mode.

Input signal Optical-Isolator


7 Relay Output Terminal : Set point(SP1, SP2, SP3, SP4) and Finish, Empty relay output.

(Refer "F21" setting.)

4. INSTALLATION

4-1. External Dimension & Cutting Size

(External Dimension) (unit : mm)




4-2. Installation Components

Power Cable	Communication Connector(D-SUB 9P)	Load-cell Cable

4-3. Load Cell Connector Specification

4-3-1. Load Cell Connector Specification



4-3-2. Load Cell Installation

- 1) You can connect Max 8pcs of same capacity Load cells at once. (350Ω)
- 2) You have to make horizontal balance on the ground.
- 3) If you install more than 2pcs of Load cells, use Summing box and adjust output signal difference as minimum. It can make wrong weighing process caused by each load cell's variation.
- 4) If there is some temperature difference around Load cell, it can cause wrong weight measurement.
- 5) Don't do Welding job or Arc discharge around installation place. But, there is no choice, please disconnect power cable and Load cell cable.
- 6) If you measure static electricity material, please make earth between down part and up part of Load cell.

Digital Weighing Indicator SI 4200

4-2-4. Formula to plan the precise weighing system

This "SI 4200" weighing controller's Max input sensitivity is **0.1**^µ / **Digit**.

And for precise weighing system, the following formula must be satisfied.



Caution : "Input sensitivity" means Min. output voltage variation of weighing part to change 1digit. So, please do not make large input voltage to make reliable weighing system.

	>/	<	ExBxD	A : Load cell capacity(kg)
Single Load cell use	0.2 <i>µ</i> V		А	B : Load cell Voltage(mV)
		≤	ExBxD	D : Digit
Plural Load cells use	0.2 <i>µ</i> V			E : affirmation Voltage of Load cell
			A x N	N : Number of Load cell

Example1.)

The number of Load cell : 1pcs

Load cell capacity : 500kg

Load cell Rated output : 2mV/V

Division : 0.05kg

Affirmation Voltage of Load cell: 5,000mV

Max Capacity of Weighing System : 300kg

 $- = 1 \ge 0.2 \,\mu V$

Then, estimation result for this weighing system with formula,

5000 x 2 x 0.05

500

The calculated value is larger than 0.2μ , so this system has no problem.


Example2.)

The number of Load cell : 4pcs Load cell capacity : 500kg Load cell Rated output : 2mV/V Division : 0.10kg Affirmation Voltage of Load cell : 5,000mV Max Capacity of Weighing System : 1,000kg

Then, estimation result for this weighing system with formula,

5000 x 2 x 0.10	$= 0.5 > 0.2 \mu V$
500 x 4	$-0.3 \ge 0.2 \mu v$

The calculated value is larger than 0.2μ , so this system has no problem.



5. SET-UP

5-1. Calibration


Calibration is the process of adjusting weight balance between "Real weight" on the load cell and "Displayed weight of Indicator". When you replace LOAD CELL or Indicator, you have to do Calibration process once again


5-2. Test Weight Calibration Mode (Using Test weight)

Prepare the test weight as at least 10% of your weighing scale's max capacity.

Remove "CAL-BOLT" on the indicator's front panel and press "CAL - LOCK S/W" inside.

* Remark: If "P-W" is displayed, you should input the pass word to start calibration mode.





 12. Input the weight of your "Test weight". And press key. 12. Input the weight of your "Test weight". And press key. Ex) Load Cell CAPA : 20kg, division 0.001 → Use test weight which is at least 10% of max CAPA(20kg) = minimum 2kg of test weight is needed. → Input test weight 2.000 to indicator. 	L 2.000
13. When "UP" is displayed, load your test weight on the scale (weigh bridge) Ex) Load Cell CAPA : 20kg, division 0.001	IJР
14. And press key. → Do not remove the test weight from weigh bridge.	ЦР
15. Indicator will calculate span value during 5sec.	[AL-2]
16. After finish calculation, span value will be displayed. Please remove the test weight from weigh bridge.	0.629238
 Caution : The "Test Weight's value" must be at least 10% Max capa "at least 10%" means to guarantee precise weighing process y 10% of the max capacity weight. We programmed the calibration will not be done, when you load less than 	ou have to make standard with at least
17. Press key to save all calibration process. After then it resets automatically. Now, fasten the Calibration Bolt on the front panel.	End

Digital Weighing Indicator SI 4200


5-3. Simulation Calibration Mode (Calibrate without Test weight)

Through this "Simulation Calibration Mode" you can do simple calibration process without Test weight.

This calibration mode uses "Load cells' max capacity" and "Rated output value(mV)".


Simulation calibration's degree of accuracy is lower than test weight calibration.

By simulation calibration's characteristic, measured weight can be different with actual weight, according to load cell's actual output.



with max capacity. EX) There are 4pcs of load cells, and each load cell's Max capa is1,000kg.

Then, total Max Capacity will be 4,000 kg(1,000 x 4) and you have to input 4,000.



12. At this step input Max Output rate(mV) of load cell.

CELLOUE

13. Input Load cell Output Rate(mV/V) (refer the load cell label) Ex) Load cell Related output : 1.989 mV/V

o 198900

* Caution : Due to some variation between "Stated output rate" and "Real Output rate" of load cell, there might be some weight difference after finishing calibration. If you want to make more precise weighing process, please measure real output rate of load cell and input the

14. After inputting R.O. value, press Calculated "Span value" will be displayed.




0.087234

15. Press

Calibration Bolt.

key to save all calibration process and fasten the

measured value. Then the weight measurement will be more precise than before.



Caution : To process "Simulation Calibration" process, All indicator has its' own standard value of 2mV gap.



So, if you replaced analogue board, you have to input standard value of 2mv gap.

And you can check the this 2mV gap value on F96.

(Normally, the gap value is between 200,000 ~400,000)

Digital Weighing Indicator SI 4200

5-4. Unit Weight Calibration

"Unit Calibration" is making standard of unit weight (lea's weight) by calculating of bulk object.

If the quantity of sample is increased, the accuracy will also be increased.

This "Unit Calibration" must be processed after "SPAN calibration" (Test weight or Simulation calibration).

****** The Minimum weight of "Unit Calibration" is 1/5 of the division.

(EX. When the division is 10kg, The minimum weight of Unit Weight : 10kg * 1/5 = 2kg)

5-4-1. Unit Calibration Process

Before start "Unit Calibration Process", please finish "Span Calibration", first.

5-4-2. Unit Calibration

There are two steps to proceed "Unit Calibration".

Step 1. Zero Adjustment of Weighing Scale

2



Before process "Unit Calibration", press TARE , and make display Weight is "ZERO". or

> ZERO key.

tare key to make display "Zero", the Accuracy can be less than using [∗] In case of using

* This Step is very important to make standard of "Unit Calibration". So, if the Scale is unstable due to vibration or other abnormal variation, please remove this external effect.

Step 2. Sample Weight check and Unit weight Calculation



to save the data.

Then, Unit weight of sample and quantity of sample will be calculated automatically, and showed on the Sub-display window.

* If there is no other key input during 5 seconds, the calibration step will be terminated automatically.

5-5. Set-up


Set-up means set the F-function and make SI 4200 weighing controller will perform more accuracy.

(Considering external / internal environmental condition)

5-5-1. Enter the Set-up Mode

1). Method : Press key for 4sec. Then you can enter "F-Test" mode. Under this mode, press No.1 key and enter the "F-function" mode.

5-5-2. F-Function Change



5-6.F-Function

	Gener	al Fur	nction Setting (• Factory default set value)		
			Weighing Data Save Method Se	lection	
	(Apply on Accumulated weighing count/weight)				
E01		0	Manual Save Mode (Save when "Print" key i	nput)	
F01		1	Automatic Save Mode (Save when "Finish Relay output")		
			Weight-Back up selection	L	
EO2		0	Normal Mode		
F02	•	1	Weight Back up Mode		
			Motion Band Range settin	g	
		01	This is set "Steady" acceptable range of weigh	• 1	
F03	06	ſ	If there is vibration on weighing part, you can	set this function and reduce the vibration	
		50	effect on weighing process.	Strong Wikestion	
			1 : Weak vibration ~ 50 Zero Tracking Compensation Ran	: Strong Vibration	
		00 02 ∫	Due to external causes(Temperature, wind, and dust), there are small weight difference, indicator will ignore the weight difference and display Zero.		
			For this compensation function, indicator will estimate the weight difference is over the		
F04	02		set range during fixed time period.		
	09	09	If there is large weight difference over set ran	ge within fixed time period, the "Zero" is	
			breaking and will find new zero point.		
			Auto Zero Range setting		
		00	Within the "Auto Zero" range, weighing par weight as "Zero"	t is steady, indicator will display current	
F05	00	ſ	-	will display current weight	
		99	If the weighing part is not "Steady", indicator (Auto Zero Range : ± Set value + weight unit)		
			Digital Filter setting		
			A : Frequency Filter setting value (0~3)	If "B" set value is fixed, "A" set value	
F06	23	AB	(0 : about 200Hz/sec, 3 : about 500Hz/sec)	is large, the indicator will response	
			B : Buffer Filter setting value (1~9)	more sensitive.	
			Zero /Tare key Operation modes	selection	
	•	0	Activate when "Steady" condition, only		
F07	•	1	Always activated		
		1	11114/0 40114404		

			Zero ke	ey Operation Range sel	lection				
		0	Activated within 2%	Activated within 2% of Max Capacity					
		1	Activated within 5%	Activated within 5% of Max Capacity					
	•	2	Activated within 109	% of Max Capacity					
F08		3	Activated within 209	% of Max Capacity					
		4	Activated within 509	% of Max Capacity					
		5	Activated within 100	0% of Max Capacity					
		6	Whenever Press "Ze	ro" key (No Limit)					
	-		Tare ke	ey Operation Range sel	lection				
		0	Activated within 109	% of Max Capacity					
F09		1	Activated within 209	% of Max Capacity					
109	●	2	Activated within 509	% of Max Capacity					
		3	Activated within 100	0% of Max Capacity					
	"Key TARE" Operation Selection								
F10	●	0	Key TARE Function	Key TARE Function Not Use.					
•		1	Key TARE Function	Use					
			E	xternal Input Selection	n 1				
	Set V	alue	Input 1	Input 2	Input 3	Input 4			
		0	ZERO	TARE	TARE RESET	PRINT			
		1	RUN	STOP	TARE	TARE RESET			
F11	•	2	RUN / STOP	TARE/ TARE RESET	ZERO	PRINT			
		3	RUN	STOP	PRINT	SUB TOTAL PRINT			
		4	RUN	STOP	ZERO	PRINT			
			"STEAD	Y" condition check tin	ne setting				
		01	During the set time p	period, estimate weighin	g part's "STEADY" o	condition and display.			
F12	01	ſ	If you set small val	lue, indicator will take	"STEADY" fast, if	you set large value,			
		20	indicator will take "S	STEADY" slow.					


	Display Up-date rate selection (per 1sec)						
		0	238 times		5	31 times	
	•	1	102 times		6	26 times	
F13		2	64 times		7	23 times	
		3	47 times		8	20 times	
		4	34 times		9	18 times	
			"OVER" / "UNDER" Range Set	t value	apply s	selection	
F14	●	0	Apply only certain P/N				
1.14		1	Apply same set value to all P/N				
	SUB/GRAND Total Display mode selection						
		0	Display Accumulated weighing count and weight of current P/N				
F15	•	0	(SUB TOTAL DATA Display)				
115		1	Display Accumulated weighing count and weight of all P/N				
			(GRAND TOTAL DATA Display)				
			Minus(-) symbol displ	ay sele	ection		
F16	●	0	Display (-) symbol on the display				
110		1	Not use				
	"NEAR ZERO" relay output mode selection						
F17		0	Display weight is Zero(Including "TARE" Zero)→ Near Zero relay output			• Near Zero relay output	
1.17	1 Only Gross Zero(Net weight + TARE) \rightarrow Near Zero relay output			ro relay output			
			Equipment No. s	etting			
F18	01	01~99	Equipment No. setting with No. key				

■ Relay Output Mode Setting

***** All Relay output mode of SI 4200 model is basis on Quantity, not Weight.

	Weighing Mode selection								
	•	1	LIMIT Mode						
F21		2	PACKER Mod	PACKER Mode					
		3	CHECKER Mo	CHECKER Mode					
			Relay output	Mode(Each	weighing M	ode)			
	Weighing	Mode	Output1	Output2	Output3	Output4	Output5	Output6	
1	LIMIT MODE		SP1	SP2	Finish	Under	Over	Empty	
2	PACKER MODE		SP1	SP2	Finish	Under	Over	Empty	
3	CHECKER MODE		LOW	PASS	OVER	ERROR	N.A	Empty	

- Weighing Mode 1. Limit Mode (F21-01 setting)
 - Checker mode will be operated basis on Quantity, not Weight value.
 - This Flow Chart is based on High"/"Low" range is Zero



1. Set Value

SP1, SP2, Free Fall, (SP2 > SP1), (SP2 - Free Fall > SP1)


- * If the setting conditions are not satisfied, "E" symbol displayed and you can process the weighing.
- 2. Low / High output (LOW/HIGH value must be smaller than Max Capacity.)

LOW relay output : Relay output, when the current weight is less than (FINAL-LOW) value.

HIGH relay output : Relay output, when the current weight is more than (FINAL+HIGH) value.

3. Relay Output

Relay	Contents	Relay	Contents	
SP1	Reach to PRE 1 Set : ON	Low	Current weight < FINAL-LOW : ON	
511	Under than PRE 1 : OFF	Low	Current weight < FINAL-LOW . ON	
SP2	Reach to FINAL Set : ON	IItalı	Current weight > FINAL+HIGH : ON	
5P2	Under than FINAL : OFF	High	Current weight > FINAL+HIGH : ON	
Empty	Within "Empty Range" : ON			



• Weighing Mode 2 – Packer Mode (F21-02 setting)

1. Each Set value setting : SP1, SP2, Free Fall : (SP1 \leq SP2 – Free Fall)

- * If the setting conditions are not satisfied, "E" symbol displayed and you can process the weighing.
- 2. FINISH Relay Delay time (t1) setting (F-Function 22) : Finish relay will be Hold during "t1" period.
- 3. FINISH Relay Output time(t2) setting (F-Function 23) : Finish relay will be "ON" during "t2" period
- 4. ERROR Relay Output time(t4) setting (F-Function 28) : ERROR(Low/High) relay will be "ON" during


"t4" period. - Low/High set value must be less than FINAL value.

5. Output Relay

Relay	Contents	Relay	Contents
SP 1	Start Input : "ON"	LOW	After "t1" period,
51 1	Reach to SP 1 : "OFF"	LOW	Current weight <sp2 -low="" :="" on<="" td=""></sp2>
SD 2	Start Input : "ON"	HIGH	After "t1" period,
SP 2	Reach to SP 2 : "OFF"		Current weight > SP 2+HIGH : ON
	After SP 2 relay output,		
FINISH	Stand by during "t1" and output	EMPTY	Within "Empty Range"
	during "t2"		



- This Checker mode will be operated basis on Quantity, not Weight



1. Each Set Value Setting : SP1(Low Limit), SP2(Over Limit) – These set values must be set by Quantity.


* If the setting conditions are not satisfied, "E" symbol displayed and you can process the weighing.

2. Weight Judgment

After Weight is over than "Empty" range, and Weight is steady, indicator will have delay time(t3) and after that delay time, will output the judgment relay.

3. Output Relay

Relay	Contents	Relay	Contents		
SP1 (1)	Empty <steady 1<="" th="" weight≤sp=""><th>N.G(4)</th><th>When the weight is Under or</th></steady>	N.G(4)	When the weight is Under or		
(LOW)	(SP1 LED Lamp is ON, on Front Panel)	(Error)	Over than Standard		
SP2 (2)	SP 2 ≤ Steady Weight	E-mater(()	Within the Empty Donge		
(HIGH)	(SP2 LED Lamp is ON, on Front Panel)	Empty(6)	Within the Empty Range		
DASS (2)	SP 1 <steady 2<="" <="" sp="" th="" weight=""><th></th><th></th></steady>				
PASS (3)	(SP1 and SP2 LED Lamp is ON, on Front Panel)				



	Rounding Off Selection (Counting)				
E20	٠	0	Rounding Off Use		
F29		1	Rounding Off Not use		

Communication Mode setting (Serial Port 1. - Standard installed port)

	Parity Bit selection Mode					
		0	No Parity			
F30		1	Odd Parity			
		2	Even Parity			
			Serial Communication Speed selection			
		0	2,400bps			
		1	4,800bps			
	•	2	9,600bps			
		3	14,400bps			
F21		4	19,200bps			
F31		5	28,800bps			
		6	38,400bps			
		7	57,600bps			
		8	76,800bps			
		9	115,200bps			
			DATA Transference Method selection			
F32		0	Simplex Mode / Stream Mode			
F32		1	Duplex Mode / Command Mode			
			Print port selection (Under F32-01 setting, only)			
F33	•	0	Same port as using for Command Mode.			
1.33		1	The other port.			
			"Check-Sum" detection selection (Under F32-01 setting, only)			
F34	•	0	Check-Sum data will not be included on transferred data.			
Г34		1	Check-Sum data will be included on transferred data.			
	Serial Port Application Selection (Under F32-00 setting, only)					
F35		0	DATA Transference purpose			
1.55		1	Printing purpose (Serial Printer)			
		DA	FA Transference Mode selection (Under F32-00, F35-00 setting, only)			
F36		0	Stream Mode : Weighing Data will be transferred continuously.			

	-			
		1	Finish Mode : When Finish Relay output, only 1 time transferred.	
		2	Manual Mode : When "Print" key input, 1 time transferred.	
DATA Transference Format selection(Under F32-00, F35-00 setting, only)				
	۲	0	Format 1.	
E27		1	Format 2. (Format 1 + ID No.)	
F37		2	CAS Format	
		3	AND Format	
Print Mode selection (Under F32-00, F35-01 setting, only)				
F38	•	0	Manual Print : Whenever "Print" key input.	
F38		1	Auto Print : When Finish relay output, automatically print.	
	Stream Mode Output Data Selection			
E20	•	0	Current Weight data Output	
F39		1	Counting data Output	
Transferring DATA Byte selection				
F40		0	7 Byte data Transfer	
		1	8 Byte data Transfer	

Print Mode Setting (These settings will be apply to Serial and Parallel print)

Weight Unit selection					
F41	•	0	kg		
		1	g		
		2	t		
	Print Format selection (If you install on Standard Serial Port)				
E 42	•	0	Continuous Print : Serial No. and Weight will be printed continuously.		
F42		1	Single Print : Date, Time, S/N, ID No. Weighing Data will be print		
	Print Format selection (If you install on Optional Serial Port)				
		0	Continuous Print		
F43			Serial No. and Weight will be printed continuously.		
Г43		1	Single Print		
			Date, Time, S/N, ID No. Weighing Data will be print		
	SUB/GRAND Total Data Delete selection				
	•	0	Manual Delete Mode		
			SUN Total Delete : "Clear" key + "P/N" key		
F44			GRAND Total Delete : "Clear" key + "S/N" key		
		1	Automatic Delete Mode		
			After SUB/GRAND Total Print, Automatically Deleted.		

	Paper Withdraw Rate setting (After SUB/GRAND Total Print)			
F45	03	00~09	Whenever set value increased, 1line will be added.	
	Paper Withdraw Rate setting (After Continuous/Single Print)			
F46	03	00~09	Whenever set value increased, 1line will be added.	
		Pr	rinting Language Selection (If you install on Standard Serial Port)	
F47	●	0	KOREAN	
117		1	ENGLISH	
	Printing Language Selection (If you install on Optional Serial Port)			
F48		0	KOREAN	
1 10	•	1	ENGLISH	
		1	Minus(-) symbol Print selection	
F49	\bullet	0	Print minus(-) symbol, if the weight is minus(-).	
112		1	Ignore minus(-) symbol	
		-	Parallel Print Port selection	
	●	0	Parallel Port is not installed.	
F50		1	Share Standard Serial Port.	
		2	Share Optional Serial Port.	
		1	Function / Clear key Activation display selection	
F51	•	0	Activation display not use	
		1	Activation display use	
			Unit Weight Display Selection	
	•	0	Will not display under Zero value	
		1	Will display to one decimal point value	
		2	Will display to two decimal point value	
F52		3	Will display to three decimal point value	
		4	Will display to four decimal point value	
		5	Will display to five decimal point value	
		6	Auto display mode	
Communication Interval Setting				
F53	•	0	Fast Speed (The interval is short)	
		1	Low Speed (The interval is long)	
			Under "TARE" set, Auto Zero Function Activation Selection	
F54	●	0	Auto Zero Function use	
		1	Auto Zero Function not use	

■ Other Setting

	Conder "Other setting mode", you can not move to other function directly. EMPTY Range setting			
F80	X.X.X.X.X.X. (0.0.0.0.1.0)	 You can set "EMPTY" Range. Within set range, indicator will not display current weight and just display "Zero". "0.000" setting : When Net Zero, "Zero" status lamp and Near Zero relay will be output. "0.190" setting : Within 190, "Zero" Status lamp and Near Zero relay will be output. 		
		SPAN Calibration Value Check		
F89	X.X.X.X.X.X.	Span Calibration Value Check Under F-function mode, enter "PEI", "FEE"," key and press "CLEAR". After checking the value and press "CLEAR"," to exit * If you have difficulty to process Calibration again, the best way to matching the net weight and display weight is doing Calibration process once again.		
F90	DATE Check / Change F90 Check Current DATE data or you can Change to new date			
170	TIME check / Change			
F91				
Program & Hard ware Version Check				
F98 Check the Program & Hard ware version (H/W : X.XX, S/W : X.XX.X)				
Production DATE Check				
F99	F99 Check the Product's Production Year and Month.			

* Under "Other setting mode", you can not move to other function directly.

Communication Mode setting (Serial Port 2. - Optional Serial port)

This setting will be activated only when "Optional Serial Port" is installed.

Parity Bit selection Mode				
F60	●	0	No Parity	
		1	Odd Parity	
		2	Even Parity	
	Serial Communication Speed selection			
		0	2,400bps	
F61		1	4,800bps	
	•	2	9,600bps	

		3	14,400bps		
		4	19,200bps		
		5	28,800bps		
		6	38,400bps		
		7	57,600bps		
		8	76,800bps		
		9	115,200bps		
	DATA Transference Method selection				
F62	•	0	Simplex Mode / Stream Mode		
1.02		1	Duplex Mode / Command Mode		
			Print port selection (Under F62-01 setting, only)		
F63	•	0	Same port as using for Command Mode.		
1.03		1	The other port.		
			"Check-Sum" detection selection (Under F62-01 setting, only)		
F64	•	0	Check-Sum data will not be included on transferred data.		
1'04		1	Check-Sum data will be included on transferred data.		
			Serial Port Application Selection (Under F62-00 setting, only)		
F65	•	0	DATA Transference purpose		
105		1	Printing purpose (Serial Printer)		
		DA	TA Transference Mode selection (Under F62-00, F65-00 setting, only)		
	•	0	Stream Mode : Weighing Data will be transferred continuously.		
F66		1	Finish Mode : When Finish Relay output, only 1 time transferred.		
		2	Manual Mode : When "Print" key input, 1 time transferred.		
		DAT	TA Transference Format selection(Under F62-00, F65-00 setting, only)		
		0	Format 1.		
F67		1	Format 2. (Format 1 + ID No.)		
		2	CAS Format		
	Print Mode selection (Under F62-00, F65-01 setting, only)				
F68		0	Manual Print : Whenever "Print" key input.		
2.00		1	Auto Print : When Finish relay output, automatically print.		
	Stream Mode Output Data Selection				
F69		0	Current Weight data Output		
107		1	Counting data Output		


6. INTERFACE

6-1. Serial Interface (RS-232C)


RS-232C Serial Interface is sensitive/weak for electric Noise.

So, please isolate with AC power cable and use shield cable to reduce the electric noise effect.

6-1-1. Communication with PC(Personal Computer) or Other devices



6-1-2 Connection with External Display or other devices




SI 4100

SE 6125


(External Display)

6-1-3. Signal Format

- ① Type : EIA-RS-232C
- 0 Communication Method : Half-Duplex, Full Duplex, Asynchronous
- ③ Serial Baud Rate : Selectable on "F-function31"
- ④ Data Bit : 8(No Parity mode, only)Bit Refer "F30".
- ⑤ Stop Bit : 1
- 6 Parity Bit : Non, Even, Odd (Selectable on "F-function 30") Refer "F30"
- ⑦ Code : ASCII
 - STX 02H
 - ETX 03H
 - CR 0DH
 - LF 0AH
- (8) Check-Sum (Error Detecting, "F-Function 34")



6-1-5 Data Format(2) : ID Number + Data Transference (Refer "F-function 18, 37)



1 Header 1. : OL : Over Load, Under Load

ST : Display "Steady"

US : Display "Un-Steady"

2 Header 2. : NT : Net-Weight

GS : Net-Weight, under TARE.


③ Data Bit(Number) 2B(H) : "+" Plus


2D(H) : "-" Minus

2D(H) : " " Space

2E(H): "." Decimal Point

④ Unit : kg, g, t





1 Header 1. : OL : Over Load, Under Load

ST : Display "Steady"

US : Display "Un-Steady"

2. Header 2. : NT : Net-Weight

GS : Net-Weight, under TARE.

(3) Lamp Display : Current Lamp Condition (ON/Off Data)

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	Steady	1	Hold	Print	Gross Weight	Tare	Zero

④ Data Bit(Number) 2B(H) : "+" Plus


2D(H) : "-" Minus

2D(H) : " " Space

2E(H) : "." Decimal Point

(5) Unit : kg, g, t

Digital Weighing Indicator SI 4200



6-1-7. Data Format : AD – 4321 Data Transference) – AD – 4321 18byte Format

1) Header 1. : OL : Over Load, Under Load

ST : Display "Steady"

US : Display "Un-Steady"

2 Header 2. : NT : Net weight (Under Tare)

GS : Net weight (Under TARE reset)

③ Data Bit(Number) 2B(H) : "+" Plus

2D(H) : "-" Minus

20(H) : " " Space

2E(H) : "." Decimal Point

④ Unit : Kg, g, t


6-2. Current Loop Interface

"Current Loop" Interface is stronger for Electric Noise than "RS-232C" interface.

So, it can be used for long distance communication.(About 100m long distance).


***** Current Loop Interface supports, up to 9,600 Communication Speed, only.

6-2-1. Communication with Other Devices (Remote Display / External Display)



(External Display)

6-2-2. Current Loop Circuit



6-2-2. Data Format

As same as "RS-232C" Interface

6-3. Print Interface (Option 01 : Centronics Parallel Interface)

This Print Interface Option is based on "Centronics Parallel Interface", so this print interface can be connected other printers using this communication method.

But, the print format is programmed based on our "SE7300", and "SE7320" Industrial Printers, so you had better to use these printer for convenience.

Pin	Signal	Contents	RE
1	STROBE	STROBE signal	out
2	DATA0	Data(bit0) signal	out
3	DATA1	Data(bit1) signal	out
4	DATA2	Data(bit2) signal	out
5	DATA3	Data(bit3) signal	out
6	DATA4	Data(bit4) signal	out
7	DATA5	Data(bit5) signal	out
8	DATA6	Data(bit6) signal	out
9	DATA7	Data(bit7) signal	out
10	ACK	Data Response	In
11	BUSY	Busy signal	In
12 13	N.C		

6-3-1. Connector Wire Connection

Pin	Signal	Contents	RE
14	N.C		
15	N.C		
16	N.C		
17	N.C		
18	GND	GROUND	out
19	GND	GROUND	out
20		GROUND	out
21		GROUND	out
22		GROUND	out
23		GROUND	out
24		GROUND	out
25	GND	GROUND	out

6-3-5. Print Format (English)

Single Print

DATE : 2006-10-15 TIME : 10:20:30 ID_N PART SERIAL U-WEIGHT 01 10 01 0.01 kg 1.00kg 100EA DATE : 2006-10-15 TIME : 10:20:30 ID_N PART SERIAL U-WEIGHT 01 10 02 0.01 kg 1.00kg 100EA

SUB-TOTAL F	PRINT
-------------	-------

SUB-TOTAL		
DATE :	2006-10-15	
TIME :	10:30:30	
ID_N :	01	
PART :	10	
T-COUNT : T-WEIGHT : UNIT-WEIGHT : T-UNIT-COUNT	0101118	

	Continuous Print			
DA	ГЕ : 2006	-10-15	i	
TIN	1E : 10:20):30		
ID_	N PART	SERIA	L U-WEIGHT	
01	10	01	0.01 kg	
	1.00kg		100EA	
01	10	02	0.01 kg	
	1.00kg		100EA	
01	10	03	0.01 kg	
	1.00kg		100EA	
01	10	04	0.01 kg	
	1.00kg 100EA			

GRAND TOTAL PRINT

	GRD-TOTAL		
DATE :		2006-10-15	
TIME :		10:40:30	
ID_N :		01	
PART	SERIAL	U-WEIGHT	
10	2	0.01kg	
	2.000kg	2.000EA	
T-PAR	RT :	1	
T-COUNT :		2	
T-WE	IGHT :	2.000kg	
T-UN	T-COUNT :	2.000EA	


6-4. Analog Output Interface (Option 02 : 0~10V Output)

This Option card converts weight value to Analog Voltage output(0~10V) and transfers to external devices(Recorder, P.L.C), controlled by voltage output.

6-4-1. Specification

- ①. Output Voltage : 0~10V DC output
- 2. Accuracy : More than 1/1,000

6-4-2. Circuit



* This Voltage output is proportioned on weight calibration and outputs 0~10V.


6-4-3. Output Adjustment

- ① This output is adjusted as when the weight is "Zero", output is 0V and When the weight is "Full capacity", output is 10V.
- ② If you need additional adjustment, please adjust with "VR1(Zero)", "VR2(Span) on the Analog Output PCB.
- ※ Remark

This Analog option card converts Displayed weight value(Micro-process data) to analog value on D/A Converter(Digital to Analog converter)

This D/A Converter has Max 1/4,000 accuracy, so this output is not suitable for high accuracy application, like more than 1/3,000.

6-4-4. Connecter	(9pin,	"D-type"	female)
------------------	--------	----------	---------



* For 0~5VDC or 1~5VDC analog output, please inform when you inquiry.


6-5. Analog Output Interface (Option 03 : 4~20mA Output)

This Option card converts weight value to Analog Electric Current output(4~20mA) and transfers to external devices(Recorder, P.L.C), controlled by electric current output.

6-5-1. Specification

- ①. Output Current : 4~20mA (Output Range : 2~22mA)
- ②. Accuracy : More than 1/1,000
- ③. Temperature Co-efficiency : 0.01% $^\circ C$
- (4). Max Loaded Impedance : Max 500 Ω
- When Weight display is "Zero", 4mA current will be output, when Weight display is "Full Capacity", 20mA current will be output.

6-5-2. Circuit



* "LO" terminal is not a "GND", so this "LO" terminal do not be connected with other "GND" terminal on other devices.


6-5-3. Output Adjustment

- ① This output is adjusted as when the weight is "Zero", output is "4mA" and When the weight is "Full capacity", output is "20mA".
- ② If you need additional adjustment, please adjust with "VR1(Zero)", "VR2(Span) on the Analog Output PCB.
- % Remark

This Analog option card converts Displayed weight value(Micro-process data) to analog value on D/A Converter(Digital to Analog converter)

This D/A Converter has Max 1/4,000 accuracy, so this output is not suitable for high accuracy application, like more than 1/3,000.

6-5-4. Connecter (9pin, "D-type" female)



6-6. Serial Interface (option 04 : RS-232C/422/485)

RS-422/485 serial interface is more stable for electric noise effect compare with other communication method, using electric current difference.

But, install isolated place from Power cable or other electric cables and wires, and please use shielded cable for better performance. Recommendable communication distance is about 1.2km.

6-6-1. Signal Format


- ①. Type : RS-422/485
- 2. Format : Baud Rate : Refer "F-function 31".

Data Bit : 7 or 8(No Parity)

Stop:1

Parity Bit : Even, Odd, No Parity (Selectable)


Code : ASCII (STX 02H, ETX 03H, CR 0DH, LF 0AH)



6-6-2. Data Format

Same as RS-232C (Refer "6-1. Serial Interface")

6-6-3. RS-485 Circuit (In case of RS-485, only Use No6 and 7 pin)



6-7. BCD Input (Option 05) – Input for Part No. selection.

This "BCD interface" option card can be applied on PLC (Programmable Logic Controller), or Score Board applications.

Each Input circuit is isolated with "Photo-Coupler", from external devices electrically.


21	 → 1X1
14	 → 1X2
2	
0 15	→ 1X4
0 3	► 1X8
16	→ 10X1
0 4	 10X2
0 17	> 10X4
0 18	NC
20 0 8 0 21 0 9 22 0 10 0 23	
0 23 0 11 0 24 0 12	


Digital Weighing Indicator SI 4200

6-8. BCD Output Interface(Option 06)

This "BCD interface" option card can be applied on PLC (Programmable Logic Controller), or Score Board applications.

Each Input circuit is isolated with "Photo-Coupler", from external devices electrically.





F-function setting for BCD OUT			
F - No.	Set value	F - No.	Set value
F30	0	F60	0
F31	2	F61	2
F32	0	F62	0
F33	0	F63	0
F34	0	F64	0
F35	0	F65	0
F36	0	F66	0
F37	0	F67	0
F38	0		

6-9. Command Mode

Under "Command Mode", Indicator will recognize the receipt of Order based on 02h(Header) and 03h(END) signal, and transfers ACK(06)/ NAK(15).

6-9-1	Read Command	l (Standard Se	erial Port and C	Optional Port is same.)
0 / 1.1		(Diandana De	liui i oit ullu C	phonul i ort is sume.

P.C ->> SI 4200	Command	SI 4200 Response
		Current Weight Data (Including Decimal Point)
STX ID NO. RCWT ETX	Current Weight	-STX ID NO. RCWT ST/US,NT/GS,± Current
		Weight(7/8byte) Weight unit(2byte)ETX
		Sub-Total Data(Including Decimal Point)
STX ID NO. RSUB ETX	Sub-Total Data	-STX ID NO. RSUB P/N(2byte) ,S/N(6byte), Accumulated
STAID NO. KSOD ETA	Sub-Total Data	Weight(11byte) Weight Unit(2byte), Accumulated
		Count(10byte), Count Unit(2byte),ETX
		GRD-Total Data(Including Decimal Point)
STX ID NO. RGRD ETX	GRD-Total Data	-STX ID NO. RGRD No. of P/N(2byte), Total S/N(6byte)
51X ID NO. KORD E1X	GKD-Total Data	Accumulated Weight(11byte), Weight unit(2byte),
		Accumulated Count(10byte), Count unit(2byte), ETX
STX ID NO. RSNO ETX	S/N Data	Serial No. data
	5/11 Data	-STX ID NO. RSNO S/N(6byte) ETX
STX ID NO. RFIN ETX	Finished Weight	Finished Weight(Including Decimal Point)
STAID NO. KI'IN ETA		-STX ID NO. RFIN Finished Weight(7/8byte) ETX
STX ID NO. RTIM ETX	Current time	Current Time
	Current time	-STX ID NO. RTIM Current Time(6byte) ETX
STX ID NO. RDAT ETX	Current Date	Current Date
		-STX ID NO. RDAT Current Date(6byte) ETX
STX ID NO. RTAR ETX	TARE Data	TARE Weight(Including Decimal Point)
		-STX ID NO. RTAR TARE Weight(7/8byte) ETX
STX ID NO. RPR1 ETX	SP1 data	SP1 set value(No Decimal Point)
	511 dutu	-STX ID NO. RPR1 SP 1(6byte) ETX
STX ID NO. RPR2 ETX	SP2 data	SP2 set value(No Decimal Point)
	51 2 uata	-STX ID NO. RPR2 SP2(6byte) ETX
STX ID NO. RFRE ETX	Free Fall data	Free Fall value(No Decimal Point)
		-STX ID NO. RFRE Free Fall(6byte) ETX
STX ID NO. RLOW ETX	Low data	LOW range value(No Decimal Point)
	Low data	-STX ID NO. RLOW LOW(6byte) ETX
	TT 1 1 .	HIGH range value(No Decimal Point)
STX ID NO. RHIG ETX	High data	-STX ID NO. RHIG HIGH(6byte) ETX

STX ID NO. RPNO ETX	P/N data	Part No.
		-STX ID NO. RPNO P/N (2byte) ETX
STX ID NO. RCNT ETX	Current Count	Current Count No.
		- STX ID NO. RCNT Count No. ETX
STX ID NO. RUWT ETX	Unit Weight	Current Unit Weight (8byte)
		-STX ID NO. RUWT Current Unit Weight EXT

6-9-2. Write Command

P.C ->> SI 4200	Command	SI 4200 Response	
STX ID NO. WZER ETX	Make ZERO	ACK or NAK	
STX ID NO. WTAR ETX	TARE SET	ACK or NAK	
STX ID NO. WTRS ETX	TARE RESET	ACK or NAK	
STX ID NO. WPRT ETX	PRINT	ACK or NAK	
STX ID NO. WSPR ETX	SUB-TOTAL PRINT	ACK or NAK	
STX ID NO. WGPR ETX	GRAND-TOTAL PRINT	ACK or NAK	
STX ID NO. WSTC ETX	SUB-TOTAL PRINT DELETE	ACK or NAK	
STX ID NO. WGTC ETX	GRAND-TOTAL PRINT DELETE	ACK or NAK	
STX ID NO. WSTR ETX	SART	ACK or NAK	
STX ID NO. WSTP ETX	STOP	ACK or NAK	
STX ID NO. WTIM TIME(6byte) ETX	TIME CHANGE	ACK or NAK	
STX ID NO. WDAT DATE(6byte) ETX	DATE CHANGE	ACK or NAK	
STX ID NO. WPR1 SP1(7/8byte) ETX	SP1 SETTING	ACK or NAK	
STX ID NO. WPR2 SP2(7/8byte) ETX	SP2 SETTING	ACK or NAK	
STX ID NO. WFRE FREE FALL(5byte) ETX	FREE FALL SETTING	ACK or NAK	
STX ID NO. WLOW LOW7/8byte)ETX	LOW SETTING	ACK or NAK	
STX ID NO. WHIG HIGH(7/8byte) ETX	HIGH SETTING	ACK or NAK	
STX ID NO. WPNO PART No.(2BYTE) ETX	P/N CHANGE	ACK or NAK	
STX ID NO. WSNO S/N(6byte) ETX	Serial No. CHANGE	ACK or NAK	

• How to Calculate Check sum.

Sum the value from "STX" to "ETX" and converts to ASCII(2byte) and transfer.

Convert the Sum value(HEX) to ASCII and transmit(28byte) .

- ex) The sum HEX value from STX to ETX(02,30,31,52,43,57,54,03) is 1A6h.
- Then, divide 1A6h by 100h(1A6h/100h). the rest of result is A6h.

Calculated remainder value is A6h, then convert A6h to ASCII, 41(A), 36(6), and transfer.

/-1. Ebau (ch instanation			
Error	Cause	Treatment	Remark
Weight Value is unstable	 Load cell broken Load cell isolation resistance error Weighing part touches other devices or some weight is on the weighing part Summing Board Error 	 Measure input/output resistance of Load cell. Measure Load cell isolation resistance Check attach point with other devices. 	 Input Resistance of "EXC+" and "EXC-" is about 400Ω. ±30 Output Resistance of "SIG+" and "SIG-" is about 350Ω. ±3.5 Isolate Resistance is more than 100MΩ
Weight Value is increased regular rate, but not return to "Zero"	 Load cell Error Load cell connection Error 	 Check Load cell conn Measure Load cell Re 	
Weight Value is increased to under Zero	Load cell Output wire (SIG+, SIG-) is switched	Make wire correction	
"UN PASS" display	Load cell broken or Indicator connection Error Power was "ON" when some weight is on the load cell?	Load cell Check Load cell connection Check Remove weight on the Load cell	
"OL" or "UL" display	 Load cell broken or Indicator connection Error Loading over than Max Capa. 	 Load cell Check Load cell connection Remove over loaded 	

7. Error & Treatment

7-1. Load Cell Installation

7-2. Calibration Process

Error	Cause	Treatment	
Err 01	When Maxcapacity/digit value is over 20,000	Re-input the Max Capacity, less than 20,000 (Max Capacity / Digit)	
Err 04	Standard weight value is over than Max Capa	Re-input Standard weight value with Number keys, under Max Capacity	
Err 05	Standard weight value is less than 10% of Max Capa	Re-input Standard weight value with Number keys, more than 10% of Max Capacity	
Err 06	 Amp. Gain is too big Sig+ and Sig- wire connection error Test weight is not loaded 	Check standard weight's weight with set value. If there is difference between set value and real weight, please re-input the value (set value is too small)	
Err 07	 Amp. Gain is too small Sig+ and Sig- wire connection error Test weight is not loaded 	Check standard weight's weight with set value. If there is difference between set value and real weight, please re-input the value (set value is too big)	
Err 08	Under "F-function" model, set value is "N.A"	Check the correct value and re-input	
Err A	When there is continuous vibration on the weighing part,, indicator can not process calibration any more.	 Find vibration cause and remove Load cell check Load cell cable and connecting condition check 	

Digital Weighing Indicator SI 4200

Error No.	Display	Cause	Treatment	
No.1	"CELL- Er" or "OL"	 Load cell Error Load cell cable Error Load cell connection Error A/D Board Error It displays under 5000 or over520000. 	 Under "TEST" mode 1, check analogue value. If you can not get any analogue value or there is no change although adding load, please check load cell, load cell cable, connection conditions first. Replace another load cell, and check the indicator condition. If you have same problem, please replace new indicator and check A/D board error. 	
No.2	"Un-Pass"	 Power is ON, when some materials are on weighing part. Under "Normal Mode", if there are more than 20% loading of Max capacity, "Un- Pass" display will be appeared and indicator will stay until removing the load. Setting Back-up mode it can memory empty value, and it becomes set value without displaying "Un-pass") 	 If you set "Normal Mode", please check weighing part empty or not before turn on the power. If there are some materials in/on weighing part, please remove those materials and turn on the power. Please try to set F02-01(Back-up) mode so that the indicator can remember first empty value. Winder "UNPASS", please press 	
No.3	"FN-SET"	 When "FN-Memory" is defected When the "FN-Memory" is empty. 	1. Please contact the distributor or Head Office.	
No.4	"P-Err"	UnderParallelPrinterisconnected and installed.1.Parallelprinterinterfaceisdefected or disconnected.	 Please check connection of the print cable. Please check the trouble of print. ※ If you only install "Parallel Print" option card, you can check to do. 	

7-3. Digital Weighing Indicator

* Under "CELL-Er", Relay will not be Output, and Analogue Output(4~20mA/0~10V), either.

7-4. Indicator Test mode

Through this "Test Mode", you can check basic conditions of Indicator.

This Test consists with total 7 tests.

7-4-1. Enter "Test Mode"



key for 4sec, then display will show "F-Test".

Under this display, press No.2 key and enter the "Test Mode".

Under "Test Mode", please choose each test and check the basic conditions of Indicator.

If you want to exit from each "Test Mode", press key.

7-4-2. Test Mode

Test Mode	Contents
Test 1. Analogue Value Test	Under "TEST" display, press No.1 key and Enter "TEST1" mode. Under this mode, you can check the A/D value. If the A/D value is close to 520,000, or there is no change although pressing or loading some force on/in weighing part, please check load cell, load cell, cable, connecter, A/D board.
Test 2. Key test	Under "TEST" display, press No.2 key and Enter "TEST2" mode. Press each key, and check the pressed key is operated.
Test 3. Output Relay Test	 Under "TEST" display, press No.3 key and Enter "TEST3" mode. This Test will be operated automatically from Relay1 to Relay6. * This test will operate automatically, so please remove all materials in/on weighing parts. If you can not remove materials, please remove relay terminals.
Test 4. External Input Test	Under "TEST" display, press No.4 key and Enter "TEST4" mode. If you press External input S/W, the External S/W No. will be displayed. If the S/W No. is not displayed, please check connecting condition.
Test 5. Communication Test (Com. Port 1)	Under "TEST" display, press No.5 key and Enter "TEST5" mode. After connecting No.2 and 3 pin of 9pin connector, you can test communication condition, like TXD or RXD/TXD. If there is an error in communication, "232-Err" will be displayed with 3times buzzer sound. The communication is working properly, "232Pass" will be displayed with one time buzzer sound.
Test 6. Communication Test (Com. Port 2)Under "TEST" display, press No.6 key and Enter "TEST6" mode.After connecting No.2 and 3 pin of 9pin connector, you can test commu condition, like TXD or RXD/TXD. If there is an error in communication, "232-Err" will be displayed with 3time sound. The communication is working properly, "232Pass" will be displayed with time buzzer sound.	
Test 7. BCD IN Test	This test is for "BCD Input". If you install "BCD IN" option card, you can test this option card operation through this Test mode.
Test 8. BCD OUT	This test if for "BCD out" Through this test mode, you can check operation of BCD output.

WARRANTEE CETIFICATION

This product is passed "Sewhacnm"s strict quality test.

If there is defect of manufacturing or abnormal detection within warrantee period, please contact our Agent or Distributor with this Warrantee certificate.

of Distributor with this warrance certificate.

Then, we will repair or replace free of charge.

WARRANTEE CLAUSE

1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date

2. Warrantee Exception Clause

- Warrantee period is expired.
- Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm's permission.
- Any kinds of Mal-function, Defection, or External damage, caused by operator
- Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent.
- Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this manual.
- Any kinds of Mal-function, Defection caused by "Force Majeur", like Fire, Flood.
- Without presentation of this "Warrantee Certification".
- 3. Other
- Any kinds of "Warrantee Certification" without authorized Stamp is out of validity

Manufacturer : SEWHACNM Co.,Ltd.	Product	Digital Weighing Indicator
	Model	SI 4200
#504, 302Dong, 397, Seokcheon-ro, Ojeong-gu,	Serial No.	
Bucheon-si, Gyeonggi-do, Korea	AUTHORIZED STAMP	Sewha CNM Co.,Ltd
Tel : +82 70) 4754 6140		
Fax :+82 32) 624 0065		
sales@sewhacnm.co.kr		
http://www.sewhacnm.co.kr		
Made in KOREA		